


555-7071-210

Meridian 1 Option 11

Meridian Mail Card Option

Installation and Maintenance

Release 9.0 Standard 3.0 March 1994



Meridian 1 Option 11

Meridian Mail Card Option

Installation and Maintenance

NTP number: 555-7071-210

Publication number: P0746551

Software release: 9.0

Document version: Standard 3.0

Date: March 1994

Copyright © 1994 Northern Telecom

All rights reserved

Printed in the United States of America

The information contained in this guide is subject to change without notice. Northern Telecom reserves the right to make changes in design or components as progress in engineering or manufacturing may warrant.

FCC registration number: HKS 23J06324-PF-E

BIX, Generic X11, Meridian 1, and Meridian Mail are trademarks of Northern Telecom. Other products mentioned in this guide may be trademarks or registered trademarks of their respective companies and are hereby acknowledged.

Publication history

March 1994

Standard version 3.0 released for Meridian Mail Release 9.

Changes since MM-8:

- Greater flexibility during software installation which allows you to easily customize your system for improved security.
- Configuration of voice ports for basic service, full service, and multimedia.
- Changes to the channel expansion procedure.

February 1994

Standard version 2.1 released for the up-issue of Meridian Mail Release 8.

April 1993

Standard version 2.0 released for Meridian Mail Release 8.

August 1991

Standard version 1.1 released for system 1.10.

May 1991

Standard version 1.0 released.

Contents

About this guide

ix

- Assumptions ix
- Inside this guide ix
- Conventions xi
- Recommended reading xii
 - Hospitality and networked systems xii
 - The Meridian 1 PBX xii

Hardware installation

1-1

- Precautions 1-3
- Removing the cover 1-4
- Installing the RSM Breakout Assembly (NTAK18AA/BA) 1-5
- Installing the Meridian Mail cards 1-7
 - Inserting the 68k Card (NTAK14BA) 1-7
 - Assembling and inserting the DVP Card (NTAK15AB) 1-9
 - Assembling and inserting the Disk/Power Supply Card (NTAK13AA) 1-11
 - The final installation 1-13
- Installing the external tape drive 1-14
 - Inserting a tape 1-15
 - Removing a tape 1-16
- Removing the external tape drive 1-16
- Installing a printer 1-16
 - Connecting and configuring the LA75 Plus Companion printer 1-17
 - Connecting and configuring the HP ThinkJet printer 1-18
 - Configuring Meridian Mail 1-21

System installation and modification

2-1

- The software tape 2-1

-
- Keycodes and labels 2-1
 - Serial numbers 2-2
 - Modifying your system 2-3
 - Using the System Installation and Modification Utility 2-4
 - Responding to the prompts 2-5
-

Software installation

3-1

- What you need 3-1
 - Before installing the software 3-1
 - Automatic and manual configuration 3-2
 - Installing the software 3-3
 - Setting up the system 3-5
 - Using default values 3-6
 - Setting the time and date 3-6
 - Configuring the telephone sets 3-6
 - Setting the on-switch dialing restrictions 3-7
 - Assigning a System Administrator 3-8
 - Setting up the Automated Attendant/Hotel Menu 3-8
 - Setting up the Voice Services DN Table (basic systems) 3-12
 - Setting up the Voice Services DN Table (Hospitality systems) 3-14
 - Adding a block of voice mailboxes 3-17
-

Basic system procedures

4-1

- Switching between Meridian Mail and the Meridian 1 PBX 4-1
 - Logging on to the Meridian 1 PBX 4-1
 - Setting the time and date 4-2
 - Enabling and disabling the console and AML data ports 4-3
 - Determining the Meridian 1 software release number 4-3
 - For Release 17 systems and earlier 4-3
 - For Release 18 systems and later 4-4
 - Stopping Meridian Mail 4-5
 - Courtesying down the system 4-5
 - Turning Meridian Mail off 4-5
 - Starting Meridian Mail 4-6
 - After turning Meridian Mail off 4-6
 - After courtesying down the system 4-6
 - After turning off the Meridian 1 PBX 4-6
 - Backing up the system 4-7
 - Scheduling system backups 4-8
 - Restoring the system 4-9
-

-
- The Tools Menu 4-10
 - Adding a block of users 4-10
 - Deleting a block of users 4-11
 - Changing the default Meridian Mail DNs 4-12
 - Using Meridian 1 overlays 4-12
 - Changing the Voice Messaging DN 4-12
 - Changing a hardware location DN 4-14
 - Changing the other Meridian Mail DNs 4-15

Troubleshooting and maintenance **5-1**

- Troubleshooting 5-1
 - Precautions 5-2
 - Replacing components 5-3
 - Problems at start-up 5-4
 - Problems during system expansion or software upgrade 5-8
 - Tape drive problems 5-8
 - Terminal problems 5-10
 - Modem problems 5-12
 - Voice mail problems 5-12
 - System event and error reports (SEERs) 5-14
- Spares planning 5-14
- Maintaining the external tape drive 5-15
 - Cleaning the tape drive 5-16

Software upgrades and conversions **6-1**

- What you need 6-1
- Precautions 6-2
- Performing a software upgrade or conversion 6-2

System expansion **7-1**

- What you need 7-1
- Precautions 7-1
- Hardware modification 7-2
- Storage expansion 7-3
- Language expansion 7-5
- Feature expansion 7-6

Hospitality systems **8-1**

- Hardware installation 8-1

| | |
|--|-----|
| The multiport cable | 8-2 |
| The RSM Breakout Assembly | 8-2 |
| The hotel's property management system | 8-2 |
| The guest administration consoles (GACs) | 8-2 |
| Software installation | 8-3 |
| Hospitality system administration | 8-4 |

Networked systems **9-1**

| | |
|--------------------------------------|-----|
| Hardware installation | 9-1 |
| The RSM Breakout Assembly | 9-1 |
| Configuring the modem | 9-3 |
| Software installation | 9-5 |
| During initial software installation | 9-5 |
| After initial software installation | 9-5 |
| Network system administration | 9-5 |

Meridian Mail defaults **10-1**

| | |
|---------------------------------|------|
| Basic systems | 10-1 |
| Hospitality system service DNSs | 10-3 |
| Networked systems | 10-3 |

Terminal configuration **11-1**

| | |
|-----------------------------------|------|
| NT220 terminals | 11-1 |
| VT220, VT320, and VT420 terminals | 11-3 |
| HP700/22 terminals | 11-8 |
| HP700/32 terminals | 11-9 |

Disk drive configuration **12-1**

List of terms **13-1**

Index **14-1**

Figures

- Figure 1-1 An overview of hardware installation (a three-slot system) 1-2
- Figure 1-2 Removing the cover 1-4
- Figure 1-3 The RSM Breakout Assembly 1-6
- Figure 1-4 Inserting the 68k Card 1-8
- Figure 1-5 Assembling and inserting the primary DVP Card 1-10
- Figure 1-6 Assembling and inserting the Disk/Power Supply Card 1-12
- Figure 1-7 Installing the Connector Board 1-13
- Figure 1-8 Mounting the external tape drive 1-15
- Figure 1-9 The LA75 Plus Companion printer control panel 1-18
- Figure 1-10 Configuring the HP ThinkJet printer 1-20
- Figure 1-11 Enabling the HP ThinkJet printer 1-21
- Figure 2-1 A typical Card Option label 2-3
- Figure 3-1 The voice security options form 3-7
- Figure 3-2 The Thru-Dial Definition form 3-9
- Figure 3-3 The Add a Voice Menu Definition form 3-10
- Figure 3-4 The Voice Menu Definition form (continued) 3-11
- Figure 3-5 The Voice Menu Definition form (continued) 3-12
- Figure 3-6 The Add DN Information form (basic systems) 3-13
- Figure 3-7 The Add DN Information form (Hospitality systems) 3-15
- Figure 5-1 Testing voltage and resistance on the Connector Board 5-5
- Figure 5-2 Cleaning the tape head 5-17
- Figure 8-1 Hospitality system cables 8-3
- Figure 9-1 Networked system cables 9-2
- Figure 12-1 Maxtor 7080S & 7080SR disk drive configuration 12-2
- Figure 12-2 Maxtor 7080S-C disk drive configuration 12-2
- Figure 12-3 Maxtor 7120S disk drive configuration 12-3
- Figure 12-4 Maxtor LXT340SY disk drive configuration (option A) 12-3
- Figure 12-5 Maxtor LXT340SY disk drive configuration (option B) 12-4
- Figure 12-6 Quantum ProDrive 80S disk drive configuration 12-4
- Figure 12-7 Seagate ST1096N disk drive configuration 12-5
- Figure 12-8 Seagate ST1201N disk drive configuration 12-5
- Figure 12-9 Seagate ST1480N disk drive configuration 12-6
- Figure 12-10 Seagate ST3390N disk drive configuration 12-7

Tables

| | | |
|------------|--|-------|
| Table 1-1 | Hardware location configurations | 1-9 |
| Table 1-2 | LA75 Plus Companion printer default settings | 1-19 |
| Table 2-1 | Software tapes and languages | 2-2 |
| Table 4-1 | Printing a telephone set report | 4-16 |
| Table 4-2 | Printing a telephone model report | 4-16 |
| Table 4-3 | Printing an ACD queue report | 4-17 |
| Table 4-4 | Printing a hardware location report | 4-17 |
| Table 4-5 | Creating a new Voice Messaging DN | 4-18 |
| Table 4-6 | Changing a hardware location | 4-19 |
| Table 4-7 | Changing an analog telephone set | 4-19 |
| Table 4-8 | Changing a digital telephone set | 4-20 |
| Table 4-9 | Deleting a service DN | 4-20 |
| Table 4-10 | Creating a new service DN | 4-21 |
| Table 4-11 | Disabling a hardware location | 4-21 |
| Table 4-12 | Enabling a hardware location | 4-21 |
| Table 4-13 | Changing a hardware location's DN | 4-22 |
| Table 4-14 | Deleting a hardware location's DN | 4-22 |
| Table 4-15 | Creating a hardware location DN | 4-23 |
| Table 5-1 | Spares planning | 5-15 |
| Table 8-1 | Wiring for DTE PMS systems | 8-4 |
| Table 8-2 | Wiring for DCE PMS systems | 8-5 |
| Table 8-3 | Wiring for guest administration terminals (GACs) | 8-6 |
| Table 9-1 | Wiring for networked systems | 9-2 |
| Table 10-2 | Hardware location parameters for Overlay 11 | 10-3 |
| Table 11-1 | NT220 set-up values | 11-3 |
| Table 11-2 | VT220 set-up values | 11-5 |
| Table 11-3 | VT320 set-up values | 11-6 |
| Table 11-4 | VT420 set-up values | 11-7 |
| Table 11-5 | HP700/22 set-up values | 11-9 |
| Table 11-6 | HP700/32 set-up values | 11-11 |

About this guide

The Meridian Mail card option adds voice messaging capabilities to a Meridian 1 Option 11 system. This guide describes the installation and maintenance procedures for Meridian Mail hardware and software.

Assumptions

This guide assumes that the Meridian 1 system hardware and software have already been correctly installed; that all environmental conditions and electrical requirements have been met; that the system has been correctly configured as a basic, networked, or hospitality system; and that a Meridian Mail compatible video display terminal has been installed on the Meridian 1 PBX and correctly configured.

Most of the hardware installation and maintenance procedures require no special knowledge or equipment. You should be familiar with basic electronic assembly and safety procedures. The procedures for installing a networked system or a hospitality system require you to know how to wire a BIX in-building cross-connect system or similar modular distribution frame (MDF).

The software installation and maintenance procedures require no special knowledge. Some of the basic software procedures, however, require you to know how to use the Meridian Mail System Administrator terminal.

Inside this guide

“Hardware installation” (Chapter 1) describes the installation of a basic Meridian Mail card option system.

“System installation and modification” (Chapter 2) describes how to use the System Installation and Modification Utility that comes on the Meridian Mail

software tape. This utility is used to install software on new systems, modify the software on existing systems, and perform routine system maintenance.

“Software installation” (Chapter 3) describes how to install the software on a new Meridian Mail system.

“Basic system procedures” (Chapter 4) describes the basic software procedures you need to know in order to set the time and date on the Meridian 1 PBX, to stop and start the Meridian Mail system, to backup and restore a customer’s Meridian Mail data, to add and delete blocks of users, and to customize a customer’s service DNs.

“Troubleshooting and maintenance” (Chapter 5) describes the procedures you can follow should anything go wrong with Meridian Mail, and the procedures you should follow to make these problems less likely.

“Software upgrades and conversions” (Chapter 6) describes the procedures to follow when updating to the most current release of the Meridian Mail software.

“System expansion” (Chapter 7) describes the procedures to follow when adding new hardware locations or modifying the existing hardware locations, expanding the system’s disk storage, adding new languages, or enabling option features.

“Hospitality systems” (Chapter 8) describes the additional hardware installation and software procedures required in order to take advantage of Meridian Mail’s Hospitality Voice Services (HVS) capabilities.

“Networked systems” (Chapter 9) describes the additional hardware installation and software procedures required in order to take advantage of Meridian Mail’s networking capabilities.

“Meridian Mail defaults” (Chapter 10) lists the default passwords and system parameters on a Meridian Mail Card Option system.

“Terminal configuration” (Chapter 11) describes how to set up the video display terminals supported by Northern Telecom.

“Disk drive configuration” (Chapter 12) contains configuration instructions for the disk drives supported by Northern Telecom.

Conventions

The conventions on the following page are used throughout the software procedures in this guide.

Return

This form is used to represent a single key you must press on your keyboard.

Control

When entering commands like this, hold down the **Control** key while you press the character that follows (in this case “J”) in the same way you hold down the shift key to enter capital letters.

TOOLS

Letters in bold type are used to represent text you must enter at the keyboard.

Exit

This form is used to represent a “soft” key you must press on the keyboard when using the Meridian Mail System Administrator’s terminal. This will be one of the keys on the keyboard labelled **F6**, **F7**, and so on. The current configuration of soft keys is always displayed at the bottom of your screen.

More Above

Words in this type represent messages that you see on the terminal’s screen.

“Enabled”

Words in quotation marks are used to represent a selection you must make from a list of choices. An instruction in the following form is used to guide you quickly through a series of menus:

- 1 From the Main Menu, choose
“1 User Administration” → “1 Local Voice User”.

This example means choose “User Administration” from the first menu and “Local Voice User” from the next menu that appears.

System Status

Words in italic type are used to represent the name of a field. For example:

- 1 For *First Name*, enter the user’s first name and press **Return**.

System administration—The Basics: “Finding your users”

Italicized titles indicate a reference to another document associated with the Meridian Mail system. Sections within a document are enclosed in quotation marks. References to sections within this document do not include the document title.

Recommended reading

The following is a list of other documents associated with the Meridian Mail card option.

- *Meridian Mail Card Option—System Administration, The Basics* (NTP 555-7071-300)
- *How to Use Meridian Mail* (P0746553)
- *Meridian Mail—System Administration Guide* (NTP 555-7001-301)
- *Meridian Mail—System Administration Tools* (NTP-555-7001-302)
- *Meridian Mail—System Event and Error Reports* (NTP 555-7001-510)

Hospitality and networked systems

- *Meridian Mail—System Administration Guide (Hospitality)* (NTP 555-7001-302)
- *Meridian Mail Modular Option—Installation Procedures* (NTP 555-7041-210)
- *Meridian Mail—Networking Installation Guide* (NTP 555-7001-213)
- *BIX In-building Cross-connect System—Material Description* (NTP 631-4511-100)

The Meridian 1 PBX

- *Meridian 1 Option 11—Technical Reference Guide* (NTP 553-3011-100)
- *Meridian 1 Option 11—General Installation and Planning Guide* (NTP 553-3011-200)
- *Meridian 1 Option 11—Installation Guide* (NTP 553-3011-210)
- *Meridian 1 Option 11—Administration Guide* (NTP 553-3011-300)
- *Meridian 1 Option 11—Fault Clearing Guide* (NTP 553-3011-500)
- *X11 Software Guide Including Supplementary Features* (P0730610)

Hardware installation


This chapter describes the installation of a basic Meridian Mail card option system. Later chapters describe the special hardware you have to install for networked systems and hospitality systems.

The basic Meridian Mail hardware consists of the following:

- 1 68k Card (NTAK14BA)
- 1-2 DVP Cards (NTAK15AB)
- 0-4 C25 Cards (NTAK16AB)
- 1 Disk/Power Supply Card and SCSI terminator (NTAK13AA)
- 1 Disk drive for five-hour systems (A0377786) or
Disk drive for ten-hour systems (A0378251) or
Disk drive for twenty-four-hour systems (A0351371, A0602257)
- 1 Disk shield kit for mounting the disk drive to the Disk/Power Supply Card (P0743928)
- 1 Connector Board and Meridian Mail faceplate for three-slot systems (NTAK17AA) or
Connector Board and Meridian Mail faceplate for four-slot systems (NTAK17BA)

Three slots in the Meridian 1 cabinet are reserved for the 68k Card, the DVP Card and the Disk/Power Supply Card. They are labelled 10/MM1, MM2, MM3 respectively. (Refer to Figure 1-1 on page 1-2.) In four-slot systems, an additional DVP Card is placed in slot 9. You can attach up to two C25 Cards to each DVP Card.

Figure 1-1
An overview of hardware installation (a three-slot system)



The following are optional:

- External tape drive kit and SCSI cable, North America (NTAK30CA)
- External tape drive kit and SCSI cable, United Kingdom (NTAK30BA)
- External tape drive kit and SCSI cable, European Mainland (NTAK30AA)

Note: These tape drive kits each come with a power cord appropriate to their location.

- Tape Drive Wall Mounting Kit (NTAK39AA)
- 3M brand DC6250 tapes (A0368760) for system backups
- Northern Telecom Personal Printer (C2501287)
- RSM Breakout Assembly (NTAK18AA)
- RSM Breakout Assembly, with enhanced EMI protection (NTAK18BA)
- Hospitality Voice Services (HVS) Hardware Kit, including RSM Breakout Assembly (NTAK35AA)
- Networking Hardware Kit, including RSM Breakout Assembly (NTAK40AA)

The HVS and Networking Hardware Kits each contain the RSM Breakout Assembly which fits under the Meridian 1 card cage and plugs into the right-most 25-pair connector, J10.

Precautions

If you are installing an HVS or Networking system, you must install the RSM Breakout Assembly first.

You can install the Meridian Mail hardware while the Meridian 1 PBX is running, but you must ensure that the switch on the 68k Card is in the off (down) position. Failing to do so can result in damage to the components or injury to yourself.



DANGER
Shock hazard

Before removing any cards, ensure that the power switch on the 68k Card is in the off (down) position.

Before touching any components, ensure that you are properly grounded by putting on the wrist strap connected to the Meridian 1 cabinet. Static electricity can irreparably damage sensitive electronic components.




CAUTION
Static electricity

The printed circuit boards are susceptible to static damage. Before handling the PCBs take the appropriate precautions.

Removing the cover

Use a screwdriver to unlock the latches on the front of the Meridian 1 cabinet. The latches slide inwards, the cabinet cover swings down and detaches at the base. Remove the cover and put it safely aside.

Figure 1-2
Removing the cover



Installing the RSM Breakout Assembly (NTAK18AA/BA)

The RSM Breakout Assembly is a small circuit board that sits in the cavity beneath the three Meridian Mail cards and is connected to connector J10, the rightmost of the 25-pair connectors that run the length of the Meridian 1 cabinet. An MDF cable is attached to this assembly and allows the customer to connect other RS-232 devices to Meridian Mail, most notably for the Meridian Mail Hospitality Voice Services system and for networking.

The RSM Breakout Assembly is available in two varieties: NTAK18BA should be installed in areas requiring enhanced protection from electromagnetic interference, NTAK18AA can be used in all other situations. Apart from this difference, the two cards are installed in exactly the same way and function identically.



DANGER **Shock hazard**

Before installing the RSM Breakout Assembly, ensure that the 68k Card is not plugged into the back of the Meridian 1 cabinet. Turning off Meridian Mail is not enough.


If you are installing a new Meridian Mail system, install the RSM Breakout Assembly before any of the other cards.

- 1** If you are adding an RSM Breakout Assembly to an existing system:
 - a. Courtesy down Meridian Mail and turn it off. (Refer to page 4-5.)
 - b. Grasping the top three lock latches with one hand and the bottom three latches with the other, unlock all three cards simultaneously and pull the assembly out slowly until the 68k Card comes unplugged from the back of the cabinet. There is no need to remove it completely.
- 2** Remove the cable restraining bar.
- 3** Plug the end of the MDF cable equipped with a cubic ferrite ring into the RSM Breakout Assembly.
- 4** Move the small switch on the RSM Breakout Assembly to the "Normal" position as indicated on the Assembly.

- 5 Fit the RSM Breakout Assembly over the plastic extrusion that holds the right end of the cable restraining bar in place, plug it into the rightmost 25-pair connector, and secure it in place with the screw provided.
- 6 Run the MDF cable down through the Meridian 1 cabinet as shown in Figure 1-3.
- 7 Replace the cable restraining bar.

You can now install or reinstall the remaining Meridian Mail cards and turn on the Meridian Mail system.

Figure 1-3
The RSM Breakout Assembly



You can work with the RSM cable while the RSM Breakout Assembly is installed and Meridian Mail is on. For information on connecting peripheral devices to the RSM cable, refer to “Hospitality systems” (Chapter 8) or “Networked systems” (Chapter 9).

Installing the Meridian Mail cards


The 68k Card connects to the Meridian 1 PBX through the connector at the back of the Meridian 1 cabinet. One or two DVP Card assemblies and the Disk/Power Supply Card are connected to the 68k Card through the Connector Board which plugs in at the front edge of each of these cards.

Due to the force required to install the Connector Board, you should first assemble and insert the Meridian Mail cards into the card cage. The card cage keeps the cards securely in place while you plug in the Connector Board.

Inserting the 68k Card (NTAK14BA)

- 1 Ensure that the switch on the 68k Card is in the off (down) position.
- 2 Insert the card into slot 10/MM1 with the solder side to the left and the components to the right. Do not push it all the way to the back of the cabinet and do not lock the latch levers. (Refer to Figure 1-4.)

Figure 1-4
Inserting the 68k Card



Assembling and inserting the DVP Card (NTAK15AB)

A Meridian Mail card option system can have from two to twelve hardware locations according to the configurations in the following table. The number of hardware locations dictates how many people can use Meridian Mail at the same time. This includes both people leaving messages and faxes and people logged on to Meridian Mail.

Table 1-1
Hardware location configurations

| Hardware Locations | Configuration |
|--------------------|--|
| 2 | First DVP Card in slot MM2 with no C25 cards attached. |
| 4 | One C25 Card attached to first DVP Card in slot MM2. |
| 6 | Two C25 Cards attached to first DVP Card in slot MM2. |
| 8 | Second DVP Card in slot 9 with no C25 cards attached. Two C25 Cards attached to first DVP Card in slot MM2. |
| 10 | One C25 Card attached to second DVP Card in slot 9. Two C25 Cards attached to first DVP Card in slot MM2. |
| 12 | Two C25 Cards attached to second DVP Card in slot 9. Two C25 Cards attached to first DVP Card in slot MM2. |


- 1 Attach the supplied C25 Cards to the DVP Cards. Ensure that the DVP Card to be installed in slot MM2 has two C25 Cards before adding a C25 Card to the second DVP card. (Refer to Figure 1-5.)

To avoid damaging the cards, lay them on a firm, flat, and static-free surface as you push them together.

Note: Some systems may be equipped with an older DVP Card (NTAK15AA) or older C25 Cards (NTAK16AA). Do not install any of these older cards in slot 9. You can, however, attach new C25 Cards (NTAK16AB) to an old DVP Card, provided you insert the assembled cards in slot MM2 only.

- 2 Insert the assembled cards into their correct slots as described in Table 1-1 with the solder side to the left and the components to the right. Do not push them all the way to the back of the cabinet and do not lock the latch levers.

Figure 1-5
Assembling and inserting the primary DVP Card



Assembling and inserting the Disk/Power Supply Card (NTAK13AA)

The Disk/Power Supply Card contains the power supply for Meridian Mail and a place to mount the Meridian Mail disk drive.

- 1 Remove all terminators from the disk drive. Install the correct jumpers required for the model of disk drive you're installing and remove all other jumpers. (Refer to Chapter 12.)
- 2 Slide the disk shield over the disk drive and screw it into place on both sides of the drive with the four screws provided.
- 3 Connect the power cable from the Disk/Power Supply Card to the power connector on the disk drive. (Refer to Figure 1-6.)



CAUTION

Potential disk drive failure

Before installing the SCSI cable that connects the disk drive to the Disk/Power Supply Card, inspect the plugs at each end. A bent pin on one of the plugs can cause a disk drive failure.


When installing the SCSI cable, ensure that the plugs are seated properly and pushed down securely.

- 4 Connect the SCSI cable from the Disk/Power Supply Card to the SCSI connector on the disk drive.
- 5 Secure the disk shield/disk drive assembly to the card using the screws and insulating washers provided. Place the washers between the heads of the screws and the Disk/Power Supply Card.
- 6 If you have already installed the Meridian Mail software on this disk, plug the supplied SCSI terminator into the SCSI connector on the Disk/Power Supply Card.

Note: If this is a new system, you will be attaching an external tape drive to this connector and installing the software after you have finished installing the remaining Meridian Mail hardware.

- 7 Insert the assembled card into slot MM3 with the solder side to the left and the components to the right. Do not push it all the way to the back of the cabinet and do not lock the latch levers.

Figure 1-6
Assembling and inserting the Disk/Power Supply Card




The final installation

Figure 1-7 shows how to install a three-card Meridian Mail card option system into a three-plug Connector Board (NTAK17AA). If the system you are installing is equipped with a second DVP Card, you will require a four-plug Connector Board (NTAK17BA).

Note: A four-plug Connector Board can be used with a three-card system, but the fourth plug will block slot 9 so that it can't be used for any other Option 11 cards.

- 1 Ensure that the switch on the 68k Card is in the off (down) position.
- 2 Moving from left to right, plug the edge of each card into the appropriate plug on the Connector Board.

Figure 1-7
Installing the Connector Board



- 3 Slowly and carefully push the connected cards into the cabinet, until the 68k Card plugs firmly into the connector at the back of the cabinet. (The other cards do not have connections at the back of the cabinet.)
- 4 Grasping the top lock latches with one hand and the bottom latches with the other, lock all cards simultaneously into the cabinet.
- 5 If this system is to have a permanently connected external tape drive, install it now, following the procedure below.
- 6 If this is a new system and you have yet to install the Meridian Mail software, install it now, following the procedures described in Chapter 3.
- 7 Fit the Meridian Mail face plate into place so that the power switch and the LED line up with the appropriate holes. Be careful not to knock the power switch or bend the leads on the LED.

Installing the external tape drive


The external tape drive is used to install and upgrade software, and to make backups of Meridian Mail data. It can be attached permanently to the SCSI connector on the Disk/Power Supply Card or installed only when needed.

- 1 Unless you are installing Meridian Mail for the first time, courtesy down Meridian Mail and turn it off. (Refer to page 4-5.)
- 2 Set the power selector switch at the back of the tape drive to the correct voltage for your area.
- 3 Plug the tape drive's power cord into the same circuit used by the Meridian 1 cabinet.
- 4 At the back of the external tape drive, use the buttons above and below the small window to set the SCSI address to "1".
- 5 Plug the provided SCSI cable into either SCSI connector on the back of the tape drive and plug the provided SCSI terminator (A0379544) into the other connector.
- 6 Run the cable up through the bottom of the card cage, and plug the other end into the SCSI port of the Disk/ Power Supply Card. (Refer to Figure 1-6 on page 1-12.)
- 7 Run the grounding wire back down through the bottom of the cage and affix it behind the bar that runs the width of the cabinet, using one of the screws holding the bar to the front of the card cage.

- 8 If desired, mount the external tape drive below and to the right of the cabinet, following the instructions in Figure 1-8. It should be positioned so that it does not interfere with the cables that run out of the bottom of the Meridian 1 cabinet. Avoid mounting the tape drive where it will be subjected to continuous shock or vibration.
- 9 Start Meridian Mail. (Refer to page 4-6.)

Note: If you are installing Meridian Mail for the first time refer instead to the installation procedures in Chapter 3.

Figure 1-8
Mounting the external tape drive



Inserting a tape

Insert tapes with the label side to the top of the tape drive and the opening towards the handle on the front of the drive. Push the tape all the way into the drive and slide the handle to the right until it locks into place

If the tape drive has been correctly mounted on the wall, insert tapes with the label facing the wall and the opening facing upwards.

The tapes you receive from Northern Telecom are 3M brand DC6250 tapes. Be sure to use this tape format for your backups.

Removing a tape

Slide the handle on the front of the drive to the left until the tape is ejected from the drive. Do not attempt to remove a tape when the drive is running.

Removing the external tape drive

For systems not equipped with a permanently installed external tape drive, the Meridian 1 representative is responsible for all software procedures that require a tape drive and should therefore include a tape drive as part of his or her standard equipment.

To remove the external tape drive:

- 1 Courtesy Down Meridian Mail and turn it off. (Refer to page 4-5.)
- 2 Turn off the power to the tape drive and unplug it.
- 3 Detach the grounding wire from the Meridian 1 cabinet.
- 4 Unplug the SCSI cable from the Disk/Power Supply Card and install an SCSI terminator in its place.
- 5 Start Meridian Mail. (Refer to page 4-6.)



CAUTION **Potential data loss**

Whenever an external tape drive is not attached to the Disk/Power Supply Card, install the SCSI terminator in its place.

Installing a printer

Connecting a printer to the System Administrator's terminal allows the administrator to print reports using Meridian Mail's Operational Measurements function.

You can also configure Meridian Mail to print System Error and Event Reports on the same printer as they are generated. System events and error reports contain information about every system event and error that occurs on the Meridian Mail system. For more information on the content of SEERs, refer to *Meridian Mail—System Event and Error Reports*.

Meridian Mail supports two types of printer: the LA75 Plus Companion Printer; and the HP ThinkJet Printer (NT Personal Printer). If the printer you are installing is a different model, match its settings with those described in Table 1-2 on page 1-19 and Figure 1-10 on page 1-20 and use the set-up procedures described in the printer's owner's manual.

Connecting and configuring the LA75 Plus Companion printer

- 1 Connect the printer to the appropriate port at the rear of the System Administrator's terminal using the following cables:

For VT220 terminals, connect the printer to the H87575-A adapter using a BC16E-10 cable, and connect the adapter to the port labelled "PR" using an A0369499 cable.

For VT320 and VT420 terminals, connect the printer to the port labelled "Printer Port" using a BC16E-10 cable.


For NT220 terminals, connect the printer to the H87575-A adapter using a BC16E-10 cable, and connect the adapter to the port labelled "Auxiliary" using an NTND82AA/AB cable.

For HP700/22 terminals, connect the printer to the port labelled "Printer" using an A0369499 cable.

For HP700/32 terminals, connect the printer to the H87575-A adapter using a BC16E-10 cable, and connect the adapter to the port labelled "Port 2" using an A0369499 cable.

- 2 Plug the printer's AC power cord into an appropriate outlet, and turn on the power. There is no need for it to be on the same circuit as the Meridian 1 cabinet.
- 3 Ensure that the printer is turned off.
- 4 Press and hold the Set-up button on the front control panel of the printer and at the same time power on the printer.

Figure 1-9
The LA75 Plus Companion printer control panel



- 5 Release the Set-up button one to two seconds after powering on. *The printer prints a list of the default settings. When the list is complete, it goes back to the beginning of the list, reprints the first setting, and stops. Refer to Table 1-2 on page 1-19.*
- 6 If you want to change the current setting, press the left arrow key on the control panel. *The current feature number is printed again with the new setting.*
- 7 If this is not the setting you require, press the left arrow button again and the next setting for that feature number is printed. Refer to the printer's user manual for the list of options available for each feature.
- 8 Repeat step 7 until the option you want for this feature is printed.
- 9 Press the down arrow to move to the next feature.
- 10 Repeat step 6 to step 9 until you have changed all the settings to your satisfaction.
- 11 Press the Set-up button on the control panel to save the settings.

For more information, consult the printer's owner's manual.

Connecting and configuring the HP ThinkJet printer

- 1 Connect the printer to the appropriate port at the rear of the System Administrator's terminal using the following cables:

For VT220 terminals, connect the printer to the port labelled "PR" using an A0369499 cable.

For VT320 and VT420 terminals, connect the printer to the port labelled "Printer Port" using an A0376171 cable.

Table 1-2
LA75 Plus Companion printer default settings

| Feature Number | Name | Value Number | Name |
|----------------|------------------------|--------------|---------------------------|
| Generic 1 | Protocol at Power-up | 3 | Port Dependent |
| Generic 2 | Form length | 9 | 11 inches (A) |
| Generic 3 | Vertical pitch | 4 | 6 lines per inch |
| Generic 4 | Automatic advance | 1 | Selected |
| Generic 5 | Print quality control | 1 | Software control |
| Generic 6 | Port selection | 1 | Serial port |
| Generic 7 | Baud rate | 7 | 9600 |
| Generic 8 | Data bits and parity | 7 | 8-none |
| Generic 9 | Buffer control | 1 | XON/XOFF |
| Generic 10 | Error beep | 1 | One beep |
| Generic 11 | Typestyle | 1 | Internal |
| Generic 12 | Input buffer size | 1 | 8K |
| Generic 13 | Disconnect on fault | 1 | Not selected |
| DEC 1 | Horizontal pitch | 7 | 10 Char. per in. (80 Col) |
| DEC 2 | GO character pitch | 1 | US ASCII |
| DEC 3 | User pref. char. set | 1 | DEC Supplemental |
| DEC 4 | Printer ID | 4 | Conf. Level 2 (LA75 Plus) |
| DEC 5 | Text mode right margin | 2 | Wrap |


For NT220 terminals, connect the printer to the port labelled "Auxiliary" using an NT0M96DC/DD cable. Some NT220 terminals require an In-mac 328 adaptor (A0351509).

For HP700/22 terminals, connect the printer to the port labelled "Printer" using an A0369499 cable.

For HP700/32 terminals, connect the printer to the port labelled "Port 2" using an A0376171 cable.

- 2 Set the switches at the back of the printer so that they match those in the Figure 1-10.


Figure 1-10
Configuring the HP ThinkJet printer



- 3 Plug the printer's AC adaptor into an appropriate outlet. There is no need for it to be on the same circuit as the Meridian 1 cabinet.
- 4 Plug the adaptor's power cord into the socket at the back of the printer, and turn on the power
- 5 To enable the printer, press the button immediately below the power indicator lamp as shown in Figure 1-11.

For more information, consult the printer's owner's manual.

Figure 1-11
Enabling the HP ThinkJet printer



Configuring Meridian Mail

Meridian Mail is automatically configured to allow the printing of operational measurement reports. If, however you also want the printer to print system event and error reports as they occur, you must configure the printer as follows:

- 1 After you have loaded the Meridian Mail software (Chapter 3), log on to the Meridian Mail system at the System Administrator's terminal.
- 2 From the Main Menu, choose "2 General Administration"→ "1 General Options"
- 3 Set the field *SEER Printing* to "Enabled"
- 4 Press **Save**.

System installation and modification

This chapter describes how to use the System Installation and Modification Utility that comes on the Meridian Mail software tape. This utility is used to install software on new systems, modify the software on existing systems, restore systems from a backup tape, and perform routine system maintenance.

The software tape

The software tape you receive depends on the languages you order, as seen in Table 2-1 on page 2-2. If the languages you order are not contained on a single tape, you will receive more than one tape. If, for instance, you order German and Russian, you will receive the North American tape and the Europe 2 tape.

Keycodes and labels

Many of the functions available through the System Installation and Modification Utility require you to enter a special access code. This keycode is provided by your Meridian 1 representative and unlocks the capabilities you've purchased for your system, including:

- The amount of disk storage the system can use
- The number of channels and their attributes
- The number of languages
- Special Meridian Mail features, such as Networking and Hospitality Voice Services

The keycode for a system is printed on the label on the box containing the Meridian Mail software tape. Figure 2-1 is an example of a typical label for a Card Option system. You should also receive a second, duplicate label. Affix

this label to the inside of the door on the Option 11 cabinet; that way, should you misplace the software tape, you will still have the keycode you need.

Table 2-1
Software tapes and languages

| Tape | Order Number | Languages |
|---------------|---------------------|--|
| North America | NTAK72AE | North American English Canadian French American Spanish German Japanese Italian Brazilian Portuguese |
| Europe 1 | NTAK72BE | North American English European English—Female European French European Spanish German Italian Dutch |
| Europe 2 | NTAK72CE | North American English Swedish Norwegian Danish Finnish Russian |
| Europe 3 | NTAK72EE | North American English European English—Male Arabic Portuguese Turkish |
| Asia-Pacific | NTAK72DE | North American English New Zealand (Australasian) English Japanese Intec Japanese Mandarin Taiwanese Mandarin Korean |

Serial numbers

The serial number on this label—*MM Serial Number*—identifies which system the keycode is for. This keycode will not work on any other Meridian

Mail system. If you are responsible for more than one Meridian Mail system, ensure that you are always using the correct keycode for each.

Figure 2-1
A typical Card Option label

| MM SERIAL NBR 926199 | Bell Quebec Montreal Central 07 JUN 94 | NTI Number 3044912299 | | | | | | | | | | |
|---|--|--------------------------|------|-------|----------|----|------------|---|-----------|----|------------|---|
| PBX Serial Nbr 926199 | FEATURE(S) | LANGUAGE(S) 2 | | | | | | | | | | |
| | | HOURS 0024 | | | | | | | | | | |
| Out Calling Voice Menus | Voice Forms | Dual Lang Prompting | | | | | | | | | | |
| <table> <thead> <tr> <th>TYPE</th> <th>PORTS</th> </tr> </thead> <tbody> <tr> <td>Physical</td> <td>12</td> </tr> <tr> <td>Multimedia</td> <td>2</td> </tr> <tr> <td>Full Serv</td> <td>10</td> </tr> <tr> <td>Basic Serv</td> <td>0</td> </tr> </tbody> </table> | | | TYPE | PORTS | Physical | 12 | Multimedia | 2 | Full Serv | 10 | Basic Serv | 0 |
| TYPE | PORTS | | | | | | | | | | | |
| Physical | 12 | | | | | | | | | | | |
| Multimedia | 2 | | | | | | | | | | | |
| Full Serv | 10 | | | | | | | | | | | |
| Basic Serv | 0 | | | | | | | | | | | |
| MM9 UNIVERSAL KEYCODE C9DD BFE5 2CF4 AB63 1FF2 | | | | | | | | | | | | |

CARD-086

Modifying your system

Should you wish to modify your system, your Meridian 1 representative will provide you with a new keycode to unlock any new capabilities you purchase.

For example you may want to take advantage of the latest release of the software, increase your channels, and add some new features. A single new keycode will unlock all these modifications.

Precautions

This single keycode enables each of the system modification procedures you will have to perform. It is important, however, that you perform the procedures in the following order:

- Software upgrade or conversion (Refer to Chapter 6.)
- Hardware modification (Refer to page 7-2.)

- Storage expansion (Refer to page 7-3.)
- Language expansion (Refer to page 7-5.)
- Feature expansion (Refer to page 7-6.)

Failure to follow this order may cause problems with the system.

Of course, not all systems will require each of these steps—simply skip the ones you don't have to perform, but maintain the order. Don't, for instance, attempt a feature expansion before a language expansion.

Using the System Installation and Modification Utility

The System Installation and Modification Utility is run directly from the Meridian Mail software tape, as follows:

- 1 Courtesy down Meridian Mail and turn it off. (Refer to page 4-5.)

Note: *There is, of course, no need to turn Meridian Mail off if you have just installed or reinstalled the Meridian Mail hardware and have yet to turn it on.*

- 2 If one is not already connected, connect an external tape drive to the Meridian Mail Disk/Power Card and turn on the power switch at the back of the drive. (Refer to page 1-14.)

- 3 Insert the Meridian Mail software tape into the tape drive. (Refer to page 1-15.)

Note: If you ordered additional languages for your system, you may have received more than one software tape. Each software tape you receive contains the complete Meridian Mail system software, so it doesn't matter which you use to run the System Installation and Modification Utility. Only when you wish to load languages not contained on this tape will you need to insert another software tape.

- 4 Start Meridian Mail. (Refer to page 4-6.)

Just above the power switch on the 68k Card is a small LED. When the system is first turned on, the LED lights briefly and Meridian Mail proceeds with its internal diagnostics and start-up procedures. The LED should remain unlit during the entire process—which takes approximately four minutes—and then come back on and remain lit. At this point the tape drive starts reading the tape, and—after approximately three minutes—Meridian Mail displays the following menu:

System Installation & Modification Menu

- ```

1 Install an MM9 system
2 Upgrade to the latest MM9 release
3 Convert to the latest MM9 release
4 Feature Expansion
5 Hardware Modification
6 Storage Expansion
7 Language Expansion
8 More Utilities
```

Please enter the operation number:

- 5** *If this does not happen, refer to “Troubleshooting and maintenance” (Chapter 5).*

## Responding to the prompts

Many of prompts you see while using the System Installation and Modification Utility contain the standard default for the prompt. To accept the default:

- 1** Press **Return**.

To choose an alternative:

- 1** Press **↑** and **↓** to move through the list of alternatives.
- 2** Press **Return** to accept your choice.

To enter custom data:

- 1** Press **Remove** to delete the default.
- 2** Enter your data.
- 3** Press **Return**.

## Assigning hardware location attributes

Several of the functions available through the System Installation and Modification Utility require you to assign specific attributes to the hardware locations.

A Meridian Mail Card Option system can be equipped with up to twelve hardware locations. You must define these hardware locations as either voice ports or multimedia ports. A voice port requires a single hardware location, a multimedia port requires two consecutive hardware locations.

Each of the ports must also be defined as a basic-service or full-service port.

**Basic-service voice** ports can perform the two basic voice functions: Voice Menus and Interactive Voice Response (IVR).

**Full-service voice** ports can perform all the Meridian Mail voice functions available on Card Option systems, including Voice Menus and Interactive Voice Response.

**Basic multimedia** ports are not supported. All multimedia ports are full-service ports by default and use a *single* full-service port in your allocation.

**Full-service multimedia** ports can perform all the functions of a full-service voice port in addition to such multimedia functions as Fax on Demand.

When configuring the hardware location attributes, the system displays a list of the available hardware locations similar to the following:

```
Node ----- Voice Hardware Location -----
 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16
 1 M -- M -- V V Vb Vb
```

In this example hardware locations 1 to 4 are defined as two multimedia ports. Hardware locations 5 and 6 are defined as full-service voice ports. And hardware locations 7 and 8 are defined as basic voice ports.

When assigning ports on a Meridian Mail Card Option system, remember the following:

- Card Option systems have only one node and a maximum of twelve hardware locations.
- Multimedia ports require two consecutive hardware locations.
- You cannot assign more multimedia ports or full-service voice ports than you have purchased, nor can the total number of ports exceed the number determined by the keycode, whether or not you have the hardware you need.
- Each multimedia port uses a *single* full-service port in your allocation.

The following procedure allows you to change the attributes of a range of hardware locations:

- 1 At the `Select` operation: prompt, choose "Change"
- 2 For *Port Type*, choose the attributes you want for the range of hardware locations: Basic Voice, Full-service Voice, or Full-service Multimedia.
- 3 For *First Node*, choose "1".
- 4 For *First Location*, choose the first hardware location in the range.
- 5 For *Last Node*, choose "1".
- 6 For *Last Location*, choose the last hardware location in the range.  
*The list of hardware locations is displayed again to reflect the changes.*
- 7 At the prompt, `Is this correct?:`
  - a. Choose "Yes" to implement the changes.  
*If you have exceeded any of the limits to the number or type of ports, you are prompted to change the allocation.*  
  
or
  - b. Choose "No" to enter more changes.



---

## Software installation

---

This chapter describes how to install the software on a new Meridian Mail system and set up the system for the System Administrator. Once the software has been installed on a system, it will only ever need to be re-installed in the event of a disk drive failure.

After the initial installation, software can be upgraded or converted to a later release (Chapter 6), restored from backup (page 4-9), or the system can be expanded (Chapter 7).

### What you need

- The Meridian Mail software tape, NTAk72xE. (Refer to Table 2-1 on page 2-2 for the exact part number).
- The keycode for your system. (Refer to Chapter 2.)

The keycode you need is printed on the label on the box containing the Meridian Mail software tape, together with the serial number of the system. If you are responsible for more than one Meridian Mail system, ensure that you are using the correct keycode for each. If the serial number of the system does not match that on the label, the keycode will be rejected.

### Before installing the software

The Meridian 1 Option 11 PBX comes with several ACD queues predefined to process calls to Meridian Mail. These correspond to the default Meridian Mail DNs described in Chapter 10. If you are installing Meridian Mail on a newly-installed PBX, there is little chance that someone has changed these defaults. If, however, you are installing Meridian Mail on a PBX which has been operating for some time, you must ensure that these DNs have not been assigned to some other purpose:

- 1 Log on to the Meridian 1 PBX. (Refer to page 4-1.)
- 2 Print a hardware location report by following the prompts in Table 4-4 on page 4-17; and, using the hardware location table on page 10-2, verify that the default hardware location DNs have not been reassigned or altered.
- 3 Print an ACD queue report by following the prompts in Table 4-3 on page 4-17; and, referring to the parameters listed in Table 4-5, “Creating a new Voice Messaging DN,” on page 4-18 and Table 4-10, “Creating a new service DN,” on page 4-21, ensure that the default service DNs have not been reassigned or altered.
- 4 If the values in these reports are different from those in the appropriate tables, you can do one of two things:
  - a. Reassign the services that are currently using the DNs. (Refer to *Meridian 1 option 11—Administration Guide*.)
  - b. Change the DNs to DNs which are not in use, by following the procedures in “Changing the default Meridian Mail DNs” on page 4-12.

### Automatic and manual configuration

Depending on the options you choose, auto configuration can set up a series of default users, the default services listed in Chapter 10, and the automated attendant described in *Meridian Mail Card Option—System Administration, The Basics*.

It has, however, come to the attention of Northern Telecom that the standard default numbers are being circulated among a growing population of telephone “hackers” who log on to voice mail systems and use them to cause trouble or make long distance telephone calls.

With this in mind, you have the option of manually configuring your own values for these features, after installing the software.

#### Default data fill

During software installation you are prompted as follows:

```
Do you want default data fill?
```

To automatically configure your system, choose “yes.” If you choose “no” you must manually configure the system after the software installation is complete. If you choose “yes,” you still have the option of later changing some or all of the default data fill values.

**Default users**

If you request default data fill, you are prompted as follows:

Do you want default users created?

If you choose “yes,” you are prompted further for the number of users you want the system to create and the extension number of the first user in the list. The number of users you can add is restricted by the size of your disk drive. The extension numbers are restricted to those defaults defined on the Meridian 1 PBX.

**Default voice services**

If you request default data fill, you are prompted as follows:

Do you want default voice services?

The default voice services are:

- 100 Voice Menu defined as “Auto Attendant”
- 101 Thru-dialer defined as “Dial by Extension”
- 102 Thru-dialer defined as “Dial by Name”

**Default voice service DNs**

If you request default data fill, you are prompted as follows:

Do you want default voice service DNs created?

The default voice service DNs depend on the type of system you’re installing is a hospitality system, and on whether or not you requested default voice services:

|                                       | Hospitality Systems                                                                                                                        | Other Systems                                                                                    |
|---------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------|
| <b>Without Default Voice Services</b> | 7000 Guest Messaging                                                                                                                       | 7000 Voice Messaging                                                                             |
| <b>With Default Voice Services</b>    | 7000 Guest Messaging<br>7001 Express Messaging<br>7002 Hotel Menu<br>7003 Published Numbers<br>7004 Post Check-out<br>7005 Staff Messaging | 7000 Guest Messaging<br>7001 Auto Attendant<br>7002 Express Messaging<br>7003 Prompt Maintenance |

**Installing the software**

Installing the software for a Meridian Mail card option system takes about 45 minutes from start to finish, plus an extra 20 minutes for each additional language.

- 1 Run the System Installation and Modification Utility from the Meridian Mail software tape. (Refer to Chapter 2.)
- 2 From the System Installation and Modification Menu, choose "1 Install an MM9 system".
- 3 Respond to the prompts as they appear. You should be prepared to supply the following values for the system:
  - The keycode from the system's label.
  - The customer's name.  
*This is the name that appears on Meridian Mail screens and reports.*
  - The languages to install on the system.
  - The country in which the system will be operating.
  - The DSP parameters for the system.  
*These parameters are determined by the country you choose for the system. You should not have to change the default values.*
  - The desired assignment of hardware locations.
  - The DNs for the users on this system.
  - The data port locations.  
*Card option systems can have up to six data ports: the first two are reserved for the system administration terminal and the link to the Meridian 1 switch, the remaining four are the four ports available on the RSM card, if one is installed. The following are the recommended settings for these ports:*

| Location                     | Basic System | Hospitality System | Networked Systems | Networked Hospitality System |
|------------------------------|--------------|--------------------|-------------------|------------------------------|
| Node 1, Card 1, Port 1       | Console      | Console            | Console           | Console                      |
| Node 1, Card 1, Port 2       | CSL1 (AML)   | CSL1 (AML)         | CSL1 (AML)        | CSL1 (AML)                   |
| Node 1, Card 3 (RSM), Port 1 | Modem        | GAC                | Modem             | GAC                          |
| Node 1, Card 3 (RSM), Port 2 | Printer      | GAC (optional)     | Printer           | Modem                        |
| Node 1, Card 3 (RSM), Port 3 | Printer      | PMS                | Printer           | PMS                          |
| Node 1, Card 3 (RSM), Port 4 | Printer      | PMS                | Printer           | PMS                          |

*The port locations you define here must match the connections you make to the RSM Breakout Assembly. The wiring diagrams for hospitality systems (Figure 8-1 on page 8-3) and networked systems (Figure 9-1 on page 9-2) are based on these recommended values. If you customize the port locations, ensure that you change the wiring accordingly.*



Don't worry if you respond to a prompt incorrectly. Before the final installation begins you are given another opportunity to re-enter the information.

The final installation takes about 45 minutes from start to finish, plus an extra 20 minutes for each additional language. Be prepared to insert any additional language tapes as the system requests them. After the final language has been loaded, you are prompted as follows:

The operation successfully completed.

Remove the tape when it finishes rewinding and boot into service.

- 4 When the tape has finished rewinding, and the light on the front of the tape drive goes out:
  - a. Remove the tape from the drive. (Refer to page 1-16.)
  - b. Turn off the power to Meridian Mail.
  - c. Wait ten seconds.
- 5 Start Meridian Mail. (Refer to page 4-6.)
- 6 If, when you start Meridian Mail, the terminal displays the Meridian Mail logon screen but the keyboard does not respond:
  - a. Press **Control** ]
  - b. Enter **AX** **Return** to return to Meridian Mail.

If the keyboard still does not respond, refer to "Terminal problems" on page 5-10.

- 7 If the terminal is incorrectly displaying the lines on the Meridian Mail logon screen as a string of "q"s:
  - a. Press **Control** **W**.  
*You are presented with a small pop-up menu.*
  - b. Enter **IF** **Return**.  
*The screen redraws correctly.*

## Setting up the system

Before anyone can use Meridian Mail, you must ensure that the following items have been defined. After this is done, the System Administrator can customize the system by following the procedures in *System Administration—The Basics*:

- the time and date
- the Meridian Mail capabilities of each telephone set
- the Meridian Mail on-switch dialing restrictions
- a System Administrator
- the Automated Attendant
- the Voice Services DN table
- a block of voice mailboxes

### Using default values

The final three items may have already been automatically configured during software installation. You may leave them as they are or reconfigure them to your requirements. The procedures in this chapter use the suggested values defined in Chapter 10. Please note, if you choose not to use these default values, you must also change the values defined on the Meridian 1 PBX by following the procedures in “Changing the default Meridian Mail DNs” on page 4-12.

### Passwords

If you do choose to use the default values, ensure that the passwords you choose are not the same as those listed. To prevent unauthorized people from accessing your system you should follow these guidelines:

- Change passwords every three to four weeks
- Choose passwords that are easy to remember and do not write them down anywhere someone might find them
- The longer the password the better
- Do not choose things related to your organization, such as its telephone number

### Setting the time and date

The time and date must be set on the Meridian 1 PBX and on Meridian Mail:

- 1 Log on to the Meridian 1 PBX and set the PBX’s time and date. (Refer to page 4-2.)

- 2 Log on to Meridian Mail.  
*You are prompted to enter the time and date.*
- 3 Enter the time and date in the indicated format and press **Return**.

### **Configuring the telephone sets**

You must configure each of the telephone sets which are to have access to Meridian Mail so that FDN, HUNT, or a KEY value points to the Voice Messaging DN.

You can configure each telephone individually or assign them to one of the models which are predefined on every Option 11 PBX. Refer to *Option 11 Administration Guide*: “How to activate telephones.”

### **Setting the on-switch dialing restrictions**

After the initial software installation, Meridian Mail starts up with on-switch dialing completely restricted. This means that none of your users can dial Meridian Mail, nor will Meridian Mail answer their phone.

Log on to Meridian Mail

- 1 From the Main Menu, choose  
“3 Voice Administration”→  
“2 Voice Security Options”  
*The Voice Security Options form appears*

**Figure 3-1**  
The voice security options form

Voice Administration MORE ABOVE

Voice Security Options

Maximum Invalid Logon Attempts Permitted per session: 3

Maximum Invalid Logon Attempts Permitted per mailbox: 9

Maximum Days Permitted Between Password Changes: 0

Minimum Password Length: 4

External Logon: Enabled

Call Answering, Express Messaging Thru-dial restriction/permission codes: Unrestricted On\_switch Local  
Long\_distance\_1 Long\_distance\_2

List Name: On\_switch

Restriction Codes: 0 1    3 4 5 6 7 8 9

Permission Codes:                              

MORE BELOW

CARD-088

- 2 Scroll down until the first *List Name* appears.  
*The name should be "On\_switch."* (Refer to Figure 3-1.)
- 3 Move the cursor to the restriction code corresponding to the first digit in your dialing plan. Normally this will be "2."
- 4 Press .
- 5 Press .

## Assigning a System Administrator

Following the procedures in Chapter 4 of *System Administration—The Basics*, select the user you wish to make System Administrator and set the *Administrator Capability* field to "Yes". Ensure that the password for this mailbox is changed immediately from the default, and that it is changed on a regular basis.

## Setting up the Automated Attendant/Hotel Menu

The following instructions assign an Automated Attendant that functions as described on page 3-9 of *System Administration—the Basics*. An Automated Attendant is not normally part of a default Hospitality system, although you can configure the Hotel Menus DN to function as one.

It is important that you set up the Thru-Dial Definition and the Voice Menu Service before you set up the entry in the Voice Services DN table for the Automated Attendant.

### Setting up the Thru-Dial Definition

- 1 From the Main Menu, choose  
“3 Voice Administration”→  
“3 Voice Services Administration”→  
“5 Thru-Dial Definitions”  
*You are presented with a list of thru-dial definitions. On a newly installed system, this list should be blank.*
- 2 Press **Add**.  
*The Add a Thru-Dial Definition form appears. (Refer to Figure 3-2.)*

**Figure 3-2**  
**The Thru-Dial Definition form**

VS Config/Menu Applications Admin

Add a Thru-Dial Definition

Thru-Dial ID: 101 Title: Dial by Extension

Revert DN: 0

Access Password: \_\_\_\_\_ Update Password: 12345

Greeting Recorded (Voice): No

Language for Prompts: American\_English  
 Canadian\_French

Dial by: Number Name Both

DN Length Variable Fixed

Restriction/Permission Set: Custom On\_switch Local Long\_distance\_1 **MORE BELOW**

Select a softkey >

**Save** **Cancel** **Voice**

CARD-059

- 3 For *Thru-Dial ID*, enter **101**.
- 4 For *Revert DN*, enter **0**.
- 5 For *Access Password*, enter **12345**.
- 6 For *Update Password*, enter **12345**.
- 7 For *Dial by*, choose “Number”.
- 8 For *Restriction/Permission Set*, choose “On\_switch”.
- 9 Press **Save**.

### Setting up the Voice Menu Service

- 1 From the Main Menu, choose “3 Voice Administration”→

“3 Voice Services Administration”→

“7 Voice Menu Definitions”

You are presented with a list of voice menu definitions. On a newly installed system, this list should be blank.

- 2 Press **Add**.

The Add a Voice Menu Definition form appears. (Refer to Figure 3-3.)

**Figure 3-3**

**The Add a Voice Menu Definition form**

VS Config/Menu Applications Admin

Add a Voice Menu Definition

Choice of Menu Actions:

|                         |                        |                      |
|-------------------------|------------------------|----------------------|
| AS Announcement Service | CL Call                | RV Call Revert DN    |
| DS Disconnect           | EM Express Messaging   | PP Play Prompt       |
| RP Repeat Menu Choices  | MM Return to Main Menu | TS Thru-Dial Service |
| TD Time-of-Day Control  | MS Voice Menu Service  | VM Voice Messaging   |

Voice Menu ID: 100\_\_\_\_\_ Title: \_\_\_\_\_

Revert DN: 0\_\_\_\_\_

Access Password: 12345\_\_\_\_\_ Update Password: 12345\_\_\_\_\_

Greeting Recorded (Voice): No Menu Choices Recorded (Voice): No

Silent Disconnect:  No Yes

**MORE BELOW**

Select a softkey >

|      |        |       |
|------|--------|-------|
| Save | Cancel | Voice |
|------|--------|-------|

CARD-056

- 3 For *Voice Menu ID*, enter **100**.
- 4 For *Revert DN*, enter **0**.
- 5 For *Access Password*, enter **12345**.
- 6 For *Update Password*, enter **12345**.
- 7 Move downwards until the table of keys and their associated actions appears. (Refer to Figure 3-4.)

**Figure 3-4**  
**The Voice Menu Definition form (continued)**

VS Config/Menu Applications Admin

Add a Voice Menu Definition

Choice of Menu Actions:

|                         |                        |                      |
|-------------------------|------------------------|----------------------|
| AS Announcement Service | CL Call                | RV Call Revert DN    |
| DS Disconnect           | EM Express Messaging   | PP Play Prompt       |
| RP Repeat Menu Choices  | MM Return to Main Menu | TS Thru-Dial Service |
| TD Time-of-Day Control  | MS Voice Menu Service  | VM Voice Messaging   |

Access Password: 12345\_\_\_\_\_ Update Password: 12345\_\_\_\_\_

Greeting Recorded (Voice): No      Menu Choices Recorded (Voice): No

Silent Disconnect:       No  Yes

| Key | Action | Thru-Dial ID: | Comments |
|-----|--------|---------------|----------|
| 1   | TS     | 101_____      | _____    |
| 2   | —      | _____         | _____    |

**MORE BELOW**

Select a softkey >

|      |        |  |       |  |
|------|--------|--|-------|--|
| Save | Cancel |  | Voice |  |
|------|--------|--|-------|--|

CARD-057

- 8** Under the *Action* for Key 1, enter **TS**.  
*The Thru-Dial ID field appears.*
- 9** For *Thru-Dial ID*, enter **101** (the number you entered in step 3 of “Setting up the Thru-Dial Definition” on page 3-9).
- 10** Move down to the end of the form. (*Refer to Figure 3-5.*)



**Figure 3-5**  
**The Voice Menu Definition form (continued)**

VS Config/Menu Applications Admin

Add a Voice Menu Definition

Choice of Menu Actions:

|                         |                        |                      |
|-------------------------|------------------------|----------------------|
| AS Announcement Service | CL Call                | RV Call Revert DN    |
| DS Disconnect           | EM Express Messaging   | PP Play Prompt       |
| RP Repeat Menu Choices  | MM Return to Main Menu | TS Thru-Dial Service |
| TD Time-of-Day Control  | MS Voice Menu Service  | VM Voice Messaging   |

|   |   |       |       |
|---|---|-------|-------|
| 2 | — | _____ | _____ |
| 3 | — | _____ | _____ |
| 4 | — | _____ | _____ |
| 5 | — | _____ | _____ |
| 6 | — | _____ | _____ |
| 7 | — | _____ | _____ |
| 8 | — | _____ | _____ |
| 9 | — | _____ | _____ |

Initial No Response RV  
 Delayed Response PP

---

Select a softkey >

|      |        |  |       |
|------|--------|--|-------|
| Save | Cancel |  | Voice |
|------|--------|--|-------|

CARD-058

- 11 For *Initial No Response*, enter **RV**.
- 12 For *Delayed Response*, enter **PP**.
- 13 Press **Save**.

## Setting up the Voice Services DN Table (basic systems)

The Voice Services DN Table defines the DNs for Voice Messaging, Express Messaging, Voice Prompt Maintenance, and the automated attendant. If you are setting up a Hospitality system, refer to “Setting up the Voice Services DN Table (Hospitality systems)” on page 3-15.

- 1 From the Main Menu, choose
  - “3 Voice Administration”→
  - “3 Voice Services Administration”→
  - “1 Voice Service DN Table”

*You are presented with a list of defined DNs. On a newly installed system, this list should be blank.*

- 2 Press **Add**.  
*The Add DN Information form appears. (Refer to Figure 3-6.)*

**Figure 3-6**  
**The Add DN Information form (basic systems)**

VS Config/Menu Applications Admin

Add DN Information

Choice of Services:

|    |                      |    |                   |    |                     |
|----|----------------------|----|-------------------|----|---------------------|
| AS | Announcement Service | EM | Express Messaging | PM | Prompt Maintenance  |
| RA | Remote Activation    | TS | Thru-Dial Service | TD | Time-of-Day Control |
| MS | Voice Menu Service   | VM | Voice Messaging   |    |                     |

Access DN: \_\_\_\_\_

Service: \_\_\_\_\_

Comment: \_\_\_\_\_

\_\_\_\_\_

Select a softkey >

Save Cancel \_\_\_\_\_ \_\_\_\_\_ \_\_\_\_\_

CARD-055

**Automated attendant.**

- 3 For *Access DN*, enter **7001**.
- 4 For *Service*, enter **MS**.  
*The Voice Menu ID field appears.*
- 5 For *Voice Menu ID*, enter **100** (the number you entered in step 3 of "Setting up the Voice Menu Service" on page 3-10).
- 6 Press **Save**.

**Voice Messaging**

- 7 From the Voice Service DN Table, press **Add**.

8 For *Access DN*, enter **7000**.

9 For *Service*, enter **VM**.

10 Press **Save**.

### Express Messaging

11 From the Voice Service DN Table, press **Add**.

12 For *Access DN*, enter **7002**.

13 For *Service*, enter **EM**.  
*The Mailbox ID field appears, leave it blank.*

14 Press **Save**.

### Voice Prompt Maintenance

15 From the Voice Service DN Table, press **Add**.

16 For *Access DN*, enter **7003**.

17 For *Service*, enter **PM**.

18 Press **Save**.

**Note:** The default password for this service is the same as the DN. To change the password, log on to Meridian Mail using this mailbox number and press **8****4**.

## Setting up the Voice Services DN Table (Hospitality systems)

The Voice Services DN Table defines the DNs for three varieties of voice messaging (Guest Messaging, Published Numbers, and Staff Messaging), Hotel Menu, Express Messaging, and Post Check-out. If you are setting up a basic system, refer to “Setting up the Voice Services DN Table (basic systems)” on page 3-13.

1 From the Main Menu, choose  
“3 Voice Administration”→  
“3 Voice Services Administration”→  
“1 Voice Service DN Table”  
*You are presented with a list of defined DNs. On a newly installed system, this list should be blank.*

2 Press **Add**.  
*The Add DN Information screen appears. (Refer to Figure 3-7.)*

**Figure 3-7**  
**The Add DN Information form (Hospitality systems)**

**VS Config/Menu Applications Admin**

**Add DN Information**

**Choice of Services:**

|    |                       |    |                     |    |                       |
|----|-----------------------|----|---------------------|----|-----------------------|
| AS | Announcement Service  | EM | Express Messaging   | HM | Hospitality Messaging |
| CO | Post Checkout Mailbox | PM | Prompt Maintenance  | RA | Remote Activation     |
| TS | Thru-Dial Service     | TD | Time-of-Day Control | MS | Voice Menu Service    |

**Access DN:** \_\_\_\_\_

**Service:** \_\_\_\_\_

**Comment:** \_\_\_\_\_

---

Select a softkey >

Save    Cancel    [ ]    [ ]    [ ]

CARD-054

### Guest Messaging

- 3** For *Access DN*, enter **7000**.
- 4** For *Service*, enter **HM**.  
*The Auto-Login field appears.*
- 5** For *Auto-Login*, choose "Enabled".
- 6** Press **Save**.

### Hotel Menu

- 7** From Voice Service DN Table, press **Add**.
- 8** For *Access DN*, enter **7002**.
- 9** For *Service*, enter **MS**.  
*The Voice Menu ID field appears.*

- a. If you wish to have this DN function as an automated attendant, enter **100** (the number you entered in step 3 of "Setting up the Voice Menu Service" on page 3-10).
- b. Otherwise, leave this field blank.

**10** Press .

### Express Messaging

**11** From Voice Service DN Table, press .

**12** For *Access DN*, enter **7001**.

**13** For *Service*, enter **EM**.  
*The Mailbox ID field appears, leave it blank.*

**14** Press .

### Published numbers

**15** From Voice Service DN Table, press .

**16** For *Access DN*, enter **7003**.

**17** For *Service*, enter **HM**.  
*The Auto-Login field appears.*

**18** For *Auto-Login*, choose "Disabled".

**19** Press .

### Post check-out

**20** From Voice Service DN Table, press .

**21** For *Access DN*, enter **7004**.

**22** For *Service*, enter **CO**.

**23** Press .

### Staff messaging

**24** From Voice Service DN Table, press .

**25** For *Access DN*, enter **7005**.

- 26 For *Service*, enter **HM**.  
*The Auto-Login field appears.*
- 27 For *Auto-Login*, choose “Enabled”.
- 28 Press .

## Adding a block of voice mailboxes

You may choose to set up your users all at once in a single block, or the System Administrator can add one user at a time. The instructions for adding a block of users can be found on page 4-10 of this guide. The instructions for adding one user at a time can be found on page 4-8 of *System Administration—The Basics*.

Which ever method you choose, you should be aware of the following potential security problems:

- Adding a large block of mailboxes may mean that some mailboxes are not assigned to users. Once everyone has a mailbox, ensure that the extra mailboxes are deleted.
- The passwords for all new mailboxes are set to the mailbox number. Remind your users that they should change their password when they first log on, and that they should also change it on a regular basis.
- When you add a block of users, you can assign them all to a particular Class of Service. If you are concerned about unauthorized long distance calls, you should set the following fields in the Class of Service to “Local”:

- *Custom Revert Restriction/Permission Codes*
- *Extension Dialing Restriction/Permission Codes*
- *External Call Sender Restriction/Permission Codes*

Hospitality systems automatically restrict calls when a room is vacant.

---

## Basic system procedures

---

This chapter describes the software procedures you need to know in order to set the time and date on the Meridian 1 PBX, to stop and start the Meridian Mail system, to back up and restore a customer's Meridian Mail data, to add and delete blocks of users, and to customize a customer's service DNs.

Meridian Mail system administration is described in *Meridian Mail Card Option—System Administration, The Basics*.

### Switching between Meridian Mail and the Meridian 1 PBX

You use the same terminal to access both Meridian Mail and the Meridian 1 PBX. To switch to the Meridian PBX display from Meridian Mail:

- 1 Press **Control**].

To return to the Meridian Mail display:

- 1 Enter **AX** **Return**.  
*You are returned to the System Administrator screen you were using when you accessed the PBX.*

If you have any problems accessing the Meridian 1 PBX, refer to the appropriate chapters of *Meridian 1 option 11—Administration guide*.

### Logging on to the Meridian 1 PBX

To log on to the Meridian 1 PBX:

- 1 If you are in Meridian Mail, press **Control**].
- 2 Press **Return**.

- 3 If the response is OVL111 nn TTY or OVL111 nn SL1 (where nn is a two-digit number), then someone else is logged on to the system. Wait until he or she logs off and start again at step 2.

If the response is OVL000> then you are already logged on.

If the response is OVL111 nn IDLE or OVL111 nn BKGD, then you are ready to log on.

- 4 If you don't get any of these responses, enter \*\*\*\*  and start again at step 2.

If the system does not allow you to enter these four asterisks all in a row, simply enter them on one line at a time; the system will automatically move the cursor to the next line.

- 5 Enter **LOGI** .

**Note:** For this, and all other Meridian 1 commands, use uppercase letters only. You may want to press Caps Lock.

*Depending on the status of the system, you may or may not be prompted for the Meridian 1 password.*

- 6 At the prompt, enter the Meridian 1 password.  
*You are presented with the > prompt.*

## Setting the time and date

It is crucial to the integrity of Meridian Mail that the Meridian 1 PBX's time and date be set correctly. Occasionally the System Administrator is prompted for the time and date, but this does not set the Meridian 1 PBX's time and date.

- 1 Log on to the Meridian 1 PBX. (Refer to page 4-1.)
- 2 At the > prompt, enter **LD 2**
- 3 At the . prompt, enter **TTAD**  
*The system displays the day of the week together with the current date and time in the following format: DD MM YYYY HH MM SS.*
- 4 If the time and date are not correct, enter **STAD**, followed by a space, followed by the correct date and time in the above format, followed by .



**Note:** Enter the date and time exactly as shown in the format, with a space after each number. You must enter four digits for the year, and you must enter a value for the seconds.

If you make a mistake while entering these numbers, press **Return** and start entering the date and time again from the beginning.

- 5 Enter **TTAD** again to verify your entry.
- 6 Enter \*\*\*\*
- 7 Enter **AX** **Return** to return to Meridian Mail.

**Note:** It may take as long as three minutes for your changes to take effect on Meridian Mail.

## Enabling and disabling the console and AML data ports

Meridian Mail uses two data ports on the Meridian 1 switch: port 8 is used by the system administration terminal, and port 9 is used as an Application Module Link (AML).

You must enable these ports before turning Meridian Mail on, and disable them before turning Meridian Mail off. The procedures you follow depend on the release number of the Meridian 1 software running on your switch.

### Determining the Meridian 1 software release number

To determine the release number of the Meridian 1 software running on your switch:

- 1 Log on to the Meridian 1 PBX. (Refer to page 4-1.)
- 2 At the > prompt, enter **LD 22** **Return**.
- 3 At the REQ prompt, enter **ISS** **Return**.  
*The system responds with a display which includes the system release number.*
- 4 Enter \*\*\*\*

### For Release 17 systems and earlier

Use these procedures if the software running on your Meridian 1 switch is Release 17 or earlier.

**To enable the console and the AML data ports**

1 Log on to the Meridian 1 PBX. (Refer to page 4-1.)

2 At the > prompt, enter the following:

**LD 48**

**ENL ESDI 8**  to enable the console's data port

**ACMS 9**  to establish the link on port 9

3 Enter \*\*\*\*

**To disable the console and the AML data ports**

1 Log on to the Meridian 1 PBX. (Refer to page 4-1.)

2 At the > prompt, enter the following:

**LD 48**

**DIS ESDI 8**  to disable the console's data port

**DIS ESDI 9**  to disable the link on port 9

3 At the prompt, enter Y to confirm the disable.

4 Enter \*\*\*\*

**For Release 18 systems and later**

Use these procedures if the software running on your Meridian 1 switch is Release 18 or later.

**To enable the console and the AML data ports**

1 Log on to the Meridian 1 PBX. (Refer to page 4-1.)

2 At the > prompt, enter the following:

**LD 48**

**ENL AML 8 LYR2**  to enable the console's data port

**ENL AML ACMS 9 LYR2**  to establish the link on port 9

3 Enter \*\*\*\*

### To disable the console and the AML data ports

- 1 Log on to the Meridian 1 PBX. (Refer to page 4-1.)
- 2 At the > prompt, enter the following:
 

**LD 48**

**DIS AML 8 LYR2**  to disable the console's data port

**DIS AML 9 LYR2**  to disable the link on port 9
- 3 At the prompt, enter **Y** to confirm the disable.
- 4 Enter \*\*\*\*

## Stopping Meridian Mail

Before turning the power off to the Meridian Mail cards, you should courtesy down the system. This allows anyone using Meridian Mail to finish their session before the system is brought down. During this time, no further users are allowed to log on to Meridian Mail, and calls are directed to the Meridian Mail attendant.

### Courtesying down the system

- 1 Log on to Meridian Mail at the System Administrator's terminal.
- 2 From the Main Menu, choose "5 System Status and Maintenance."→"1 System Status."
- 3 Press .
- 4 At the prompt, Do you want to courtesy down the system?, use  or  to choose "Yes," and press .
 

*The display charts the progress of the courtesy down. Hardware locations are put out of service as users finish their sessions. System Status displays "CourtesyDown" when the process is complete.*

### Turning Meridian Mail off

Turning off Meridian Mail while the Meridian 1 PBX is running can cause a system error. Perform the following procedure whenever you have to turn off Meridian Mail for software upgrades, system restores, or hardware maintenance.

- 1 Disable the data ports for the console and the AML. (Refer to page 4-3.)

- 2 Turn off the power to Meridian Mail.

**Note:** The power switch is on the 68k card installed in slot 10/MM1, the off position is down and is labelled on the Meridian Mail face plate.

## Starting Meridian Mail

Meridian Mail does not start automatically, you must start it manually under the following circumstances:

- Whenever you turn off Meridian Mail to use the System Installation and Modification utility or to perform troubleshooting and maintenance procedures
- Whenever you have courtiesied the system down to perform system procedures
- Whenever the Meridian 1 PBX is turned off, as in the event of a power failure.

### After turning Meridian Mail off

- 1 Enable the data ports for the console and the AML. (Refer to page 4-3.)
- 2 Enter **AX**  to view the Meridian Mail screen.
- 3 Turn on the power to Meridian Mail.  
*The power switch is on the 68k card installed in slot 10/MM1, the on position is up and is labelled on the Meridian Mail face plate.*
- 4 Wait until the system has loaded and the logon screen is displayed. (Approximately four minutes.)  
*If this does not happen, refer to "Troubleshooting and maintenance" (Chapter 5).*

### After courtesying down the system

- 1 Log on to Meridian Mail at the System Administrator's terminal.
- 2 From the Main Menu, choose  
"5 System Status and Maintenance."→"1 System Status."
- 3 Press the Activate System soft key.

### After turning off the Meridian 1 PBX

Meridian Mail loads automatically when the Meridian 1 PBX is turned on, but you must manually log on to Meridian Mail at the System Administrator's

terminal and enter the correct time and date when prompted. Meridian Mail cannot start until these values are entered.

## Backing up the system

Before you perform any significant hardware or software procedures, you should back up the Meridian Mail system from disk to tape so that, in the event that something goes wrong, the customer's data will not be lost.

If an external tape drive is already installed, there is no need to courtesy down. The Meridian Mail system can remain active during a backup. Any changes to the system's data that occur during the backup are recorded at the very end of the backup process. However, since the backup procedure may slow down the system, we recommend you only perform backups when your system isn't busy.

The tapes you receive from Northern Telecom are 3M brand DC6250 tapes. Be sure to use this tape format for your backups.

If you encounter any problems with the following procedure, refer to "Tape drive problems" on page 5-8.

- 1 If one is not already connected, connect an external tape drive to the Meridian Mail Disk/Power Card and turn on the power switch at the back of the drive. (Refer to page 1-14.)
- 2 Log on to the Meridian Mail system at the System Administrator's terminal.
- 3 From the Main Menu, choose "2 General Administration."→  
"2 Volume Administration."
- 4 Choose the disk volume you wish to backup. (The Meridian Mail card option has only one disk volume, but you still must select it by pressing **Space Bar**.)
- 5 Press **Backup To Tape**.  
*The Disk to Tape Backup screen appears.*
- 6 Press **Immediate Backup**.
- 7 At the prompt, insert an appropriate tape into the tape drive. (Refer to page 1-15.)

- 8 Press **OK To Start Backup** .  
*The Backup Status screen appears. From here you can follow the progress of the backup. You have the option of aborting the backup or exiting to the Volume Administration screen. The backup should take about 30-60 minutes, and requires only a single tape of the appropriate size for your system.*
- 9 When the backup is complete, remove the tape and label it clearly. Include the date and time of the backup.
- 10 Press **Exit** to return to the Volume Administration screen.
- 11 Remove the external tape drive, if required. (Refer to page 1-16.)

### Scheduling system backups

Permanently installing an external tape drive allows regular backups to be scheduled. In this way, should anything go wrong with the system, there will always be a recent backup on hand.

- 1 Log on to the Meridian Mail system at the System Administrator's terminal.
- 2 From the Main Menu, choose "2 General Administration." → "2 Volume Administration."
- 3 Choose the disk volume you wish to schedule for backup. (The Meridian Mail card option has only one disk volume, but you still must select it by pressing **Space Bar**.)
- 4 Press **Backup To Tape** .  
*The Disk to Tape Backup screen appears.*
- 5 Press **Schedule Backup** .  
*The Schedule Backup screen appears.*
- 6 Fill out the appropriate fields.
- 7 Press **Save Schedule** .  
*You are returned to the Volume Administration screen. From here you can press **View Backup Schedule** to display the schedule you just entered. To edit the schedule, you must begin again at step 3.*
- 8 Turn on the power to the external tape drive and ensure that it is never turned off.

Once you have entered a schedule, backups proceed automatically. You may choose to leave the same tape in the drive at all times. New backup data will overwrite the old backup data.

**Note:** A backup tape will wear out over time. Please ensure that you replace it regularly with a new tape, according to the manufacturer's recommendations.

Scheduled backups are useful in the event of emergencies, but you should still perform an immediate full system backup before proceeding with any significant hardware or software procedures to ensure that no data is lost.

## Restoring the system

Should the system fail, a recent backup tape allows you to restore the system to the point at which the backup was made.

- 1 Run the System Installation and Modification Utility from the Meridian Mail software tape. (Refer to Chapter 2.)

**Note:** Always use the same software release that was used to create the backup. Do not, for example, attempt to restore an MM8 system using an MM9 software tape.

- 2 From the System Installation and Modification Menu, choose "8 More Utilities" → "2 Restore System from Backup".
- 3 At the prompt, insert the most recent full system backup tape you have into the tape drive and press **Return**.

**Note:** The restore process takes approximately 40-80 minutes to complete.

- 4 At the prompt:

The operation successfully completed.  
Please remove the tape and boot into service.

- a. Remove the tape from the drive. (Refer to page 1-16.)
  - b. Turn off the power to Meridian Mail.
  - c. Wait ten seconds.
- 5 Start Meridian Mail. (Refer to page 4-6.)  
*The system starts up in full service as it was when the backup was created.*

- 6 Remove the external tape drive, if required. (Refer to page 1-16.)

## The Tools Menu

The Meridian Mail Tools Menu contains several useful functions which are not used as frequently as those contained in the System Administrator's Main Menu. To access the Tools Menu:

- 1 From the Meridian Mail logon screen, press **Logon**.
- 2 At the password prompt, enter **TOOLS** **Return**.
- 3 At the password prompt, enter the System Administrator's password and press **Return**.  
*You are presented with the Tools Menu.*



### CAUTION

#### To avoid service interruptions

Do not attempt to use any function in the Tools Menu unless it is covered in this guide.

The following are brief descriptions of two of the functions available through this menu. For full descriptions of every function, refer to *System Administration Tools*.

## Adding a block of users

This function allows you to bypass the standard System Administrator's procedures and quickly add a large number of consecutive user mailboxes. To use this function:

- 1 From the Tools Menu, choose "13 Other"→"1 Add/Delete Many Users"
- 2 At the prompt, Please Specify Command?, use **↑** and **↓** to choose "Set Parameters".
- 3 At the appropriate prompts, enter:
  - The customer number, if this is a multicustomer system
  - The Class of Service number you wish to assign to the block of users. To define a Class of Service, refer to *Meridian Mail Card Option—System Administration, the Basics*.





- The voice messaging interface for these users: the Meridian Mail user interface (MMUI), or the standard defined by the voice messaging user interface forum (VMUIF). The MMUI is the interface described in *Meridian Mail Card Option—System Administration, The Basics*.
- 4 At the prompt, Please Specify Command?, choose “Add User”.
  - 5 At the appropriate prompts, enter:
    - The mailbox number of the first user in the block of users
    - The total number of users in the block.

**Note:** You can choose to be prompted before each user is added. This allows you to skip certain mailbox numbers in the block. These mailboxes will not be added.
  - 6 At the prompt, Please Specify Command?, choose “Quit”.

## Deleting a block of users

This function allows you to bypass the standard System Administrator’s procedures and quickly add a large number of consecutive user mailboxes. To use this function:

- 1 From the Tools Menu, choose “Other”→“Add/Delete Many Users”
- 2 At the prompt, Please Specify Command?, use  and  to choose “Set Parameters”.
- 3 At the appropriate prompts, enter:
  - The customer number, if this is a multcustomer system.
- 4 At the prompt, Please Specify Command?, choose “Delete User”.
- 5 At the appropriate prompts, enter:
  - The mailbox number of the first user in the block of users
  - The total number of users in the block.

**Note:** You can choose to be prompted before each user is deleted. This allows you to skip certain mailbox numbers in the block. These mailboxes will not be deleted.
- 6 At the prompt, Please Specify Command?, choose “Quit”.

## Changing the default Meridian Mail DNs

Each Meridian Mail DN is defined in two places: on the Meridian 1 PBX as an ACD-DN and on Meridian Mail as a voice services DN. The DNs on the PBX come predefined according to the defaults described in Chapter 10, but you must ensure that you define these DNs on Meridian Mail, automatically during software installation or manually by following the procedures beginning on page 3-6.

The following procedures allow you to change the ACD-DNs defined on the Meridian 1 PBX.

### Using Meridian 1 overlays

Overlays are utilities that run on the Meridian 1 PBX. The overlays described in this chapter deal primarily with printing reports of the current switch settings, and changing those settings.

Although Meridian 1 overlays can be quite versatile and may offer you a number of options for very specialized operations, we have restricted the following procedures to exactly those steps you should perform:

- Use uppercase letters only. You may want to press Caps Lock.
- Respond only to the overlay prompts listed in the procedures.
- After each response, press **Return**.
- After any prompt not listed, press **Return** to proceed to the next prompt.
- After the final prompt listed in the procedure, enter \*\*\*\* to exit the overlay.

For more information on the Meridian 1 overlays used in these procedures, refer to *X11 software guide including supplementary features*.

### Changing the Voice Messaging DN

Changing the Voice Messaging DN is not as straightforward as changing one of the other service DNs, since so many other entities within the Meridian 1 PBX refer to this DN, and each of these must be changed to refer to the new Voice Messaging DN.

This procedure assumes that the Voice Messaging DN is the DN assigned to the virtual ACD agents which answer calls to Meridian Mail.

- 1 Courtesy down Meridian Mail. (Refer to page 4-5.)

- 2 Disable the console and AML data ports. (Refer to page 4-3.)
- 3 Print a report for each type of telephone set on the switch, following the prompts in Table 4-1 on page 4-16.
- 4 Print a report for each telephone model on the switch, following the prompts in Table 4-2 on page 4-16.
- 5 Print an ACD queue report, following the prompts in Table 4-3 on page 4-17.
- 6 Print a hardware location report for card 10, following the prompts in Table 4-4 on page 4-17. The devices on this card are the virtual ACD agents which answer calls to Meridian Mail.
- 7 Delete all the ACD agents listed in this report, following the prompts in Table 4-14 on page 4-22.
- 8 Delete the old Voice Messaging DN, following the prompts in Table 4-9 on page 4-20.
- 9 Delete each of the other voice service DNs, following the prompts in Table 4-9 on page 4-20.
- 10 Using the ACD queue report you printed in step 5, delete only those queues which have night call forward (NCFW) set to the old Voice Messaging DN. Follow the prompts in Table 4-9 on page 4-20.
- 11 Create a new Voice Messaging DN, following the prompts in Table 4-5 on page 4-18.
- 12 Create new DNs for the other voice services, following the prompts in Table 4-10 on page 4-21.
- 13 Create new ACD agents to replace those you deleted in step 7, following the prompts in Table 4-15 on page 4-23.
- 14 Change each of the telephone sets on the switch and each of the telephone models so that they refer to the new Voice Messaging DN. For analog sets follow the prompts in Table 4-7 on page 4-19. For digital sets follow Table 4-8 on page 4-20.

**Note:** Analog telephone sets (type 500) can refer to the Voice Messaging DN in two different ways: using FTR FDN or using HUNT. Digital phones can refer to the Voice Messaging DN in three different way: using FDN, HUNT, or KEY. Using the reports you printed in step 3 and step 4, you must look for every occurrence

of these features that refers to the old Voice Messaging DN and change it to refer to the new Voice Messaging DN.

- 15 Nite call forward (NIT1) in the Customer Data Block may have been previously set to forward to Meridian Mail. If it was set to the old Voice Messaging DN, change it so that it refers to the new DN. Refer to *Option 11 Technical Reference Guide*.
- 16 Log on to Meridian Mail.
- 17 From the Main Menu, choose  
“3 Voice Administration”→  
“3 Voice Services Administration”→  
“1 Voice Service DN Table.”
- 18 Select the Voice Messaging DN and press **View/Modify**.
- 19 Change the value of *Access DN* to the new Voice Messaging DN and press **Save**.
- 20 Return to the Meridian 1 PBX and enable the console and AML data ports. (Refer to page 4-3.)
- 21 Start Meridian Mail. (Refer to page 4-6.)

### Changing a hardware location DN

- 1 Log on to the Meridian 1 PBX. (Refer to page 4-1.)
- 2 Disable the hardware location following the prompts in Table 4-11 on page 4-21.
- 3 Change the hardware location’s DN following the prompts in Table 4-13 on page 4-22.
- 4 Return to Meridian Mail and log on.
- 5 From the Main Menu, choose  
“5 System Status and Maintenance”→  
“3 DSP Port Status.”
- 6 Press **Disable Port** and at the prompt enter the number of the DSP port you want to change.
- 7 Return to the System Status and Maintenance Menu and choose  
“4 Channel Allocation Table.”

- 8 Change the SCN on the port you just disabled to the DN you just assigned on the PBX.
- 9 Return to the System Status and Maintenance Menu and choose "3 DSP Port Status."
- 10 Press **Enable Port** and at the prompt enter the number of the DSP port you want to change.
- 11 Return to the Meridian 1 PBX and enable the hardware location, following the prompts in Table 4-12 on page 4-21.

## Changing the other Meridian Mail DNs

The following procedure allows you to change the other service DNs defined during software installation. It should not be used to change the Voice Messaging DN.

For new DNs to function correctly you must define them in two places: on the Meridian 1 PBX and on the Meridian Mail System Administrator's terminal.

- 1 Courtesy down Meridian Mail. (Refer to page 4-5.)
- 2 Disable the console and AML data ports. (Refer to page 4-3.)
- 3 Log on to the Meridian 1 PBX. (Refer to page 4-1.)
- 4 On the Meridian 1 PBX, create a new service DN following the prompts in Table 4-10 on page 4-21.
- 5 From the System Administrator's terminal, choose  
"3 Voice Administration"→  
"3 Voice Services Administration"→  
"1 Voice Service DN Table."
- 6 Select the DN you want to change and press **View/Modify**.
- 7 Change the value of *Access DN* to the new DN you defined in step 4 and press **Save**.
- 8 Return to the Meridian 1 PBX and delete the old service DN following the prompts in Table 4-9 on page 4-20.
- 9 Enable the console and AML data ports. (Refer to page 4-3.)
- 10 Start Meridian Mail. (Refer to page 4-6.)

**Table 4-1**  
**Printing a telephone set report**

| Prompt | Response   | Comments                                                                     |
|--------|------------|------------------------------------------------------------------------------|
| >      | LD 20      | Load overlay 20.                                                             |
| REQ    | PRT        |                                                                              |
| TYPE   | _____      | Enter the type of telephone set.                                             |
| TN     | <i>c u</i> | Enter a specific location, or press <b>Return</b> for all sets of this type. |
| CUST   | _____      | Enter the customer number.                                                   |

**Table 4-2**  
**Printing a telephone model report**

| Prompt | Response | Comments                                                                              |
|--------|----------|---------------------------------------------------------------------------------------|
| >      | LD 20    | Load overlay 20.                                                                      |
| REQ    | PRT      |                                                                                       |
| TYPE   | _____ M  | Enter the type of telephone set, followed by a space, followed by <b>M</b> .          |
| MODEL  | _____    | Enter a specific model, or press <b>Return</b> for all models for this telephone set. |
| CUST   | _____    | Enter the customer number.                                                            |

**Table 4-3**  
**Printing an ACD queue report**

| Prompt | Response | Comments                   |
|--------|----------|----------------------------|
| >      | LD 23    | Load overlay 23.           |
| REQ    | PRT      |                            |
| TYPE   | ACD      |                            |
| CUST   | _____    | Enter the customer number. |

**Table 4-4**  
**Printing a hardware location report**

| Prompt | Response | Comments                         |
|--------|----------|----------------------------------|
| >      | LD 20    | Load overlay 20.                 |
| REQ    | PRT      |                                  |
| TYPE   | TNB      |                                  |
| TN     | 10       | To print all devices on card 10. |

**Table 4-5**  
**Creating a new Voice Messaging DN**

| <b>Prompt</b> | <b>Response</b> | <b>Comments</b>                                                |
|---------------|-----------------|----------------------------------------------------------------|
| >             | LD 23           | Load overlay 23.                                               |
| REQ           | NEW             |                                                                |
| TYPE          | ACD             |                                                                |
| CUST          | _____           | Enter the customer number.                                     |
| ACDN          | _____           | Enter the new service DN.                                      |
| MWC           | YES             |                                                                |
| IMS           | YES             |                                                                |
| CMS           | YES             |                                                                |
| IMA           | YES             |                                                                |
| IVMS          | YES             |                                                                |
| VSID          | 9               | Enter the number of the Meridian Mail card option ESDI link.   |
| MAXP          | 12              | Enter the maximum number of Meridian Mail ports on the system. |
| ALOG          | YES             |                                                                |
| NCFW          | 0               | Enter the attendant DN. (As defined using Overlay 15.)         |



**Table 4-6**  
**Changing a hardware location**

| Prompt | Response        | Comment                                                                                                      |
|--------|-----------------|--------------------------------------------------------------------------------------------------------------|
| >      | LD 11           | Load overlay 11.                                                                                             |
| REQ    | CHG             |                                                                                                              |
| TYPE   | 2008            |                                                                                                              |
| TN     | <i>c u</i>      | Enter the Option 11 routing address for the hardware location. (Refer to "Hardware locations" on page 10-2.) |
| KEY    | 0 ACD xxxx yyyy | xxxx is the new Voice Messaging DN and yyyy is the position ID for the hardware location.                    |

**Table 4-7**  
**Changing an analog telephone set**

| Prompt | Response                  | Comment                                                        |
|--------|---------------------------|----------------------------------------------------------------|
| >      | LD 10                     | Load overlay 10.                                               |
| REQ    | CHG                       |                                                                |
| TYPE   | 500                       | To change the analog telephone model, enter <b>500 M</b> .     |
| TN     | <i>c u</i>                | The location of the set.                                       |
| ECHG   | Yes                       | Easy change.                                                   |
| ITEM   | HUNT xxxx<br>FTR FDN xxxx | Set the appropriate ITEM to the new Voice Messaging DN (xxxx). |

**Table 4-8**  
**Changing a digital telephone set**

| Prompt | Response                                                      | Comment                                                                             |
|--------|---------------------------------------------------------------|-------------------------------------------------------------------------------------|
| >      | LD 11                                                         | Load overlay 11.                                                                    |
| REQ    | CHG                                                           |                                                                                     |
| TYPE   | <i>aaaa</i>                                                   | Enter the type of telephone set. To change a telephone model, enter <i>aaaa M</i> . |
| TN     | <i>c u</i>                                                    | Enter the location of the set.                                                      |
| ECHG   | Yes                                                           | Easy change.                                                                        |
| ITEM   | HUNT <i>xxxx</i><br>FDN <i>xxxx</i><br>KEY <i>nn fff xxxx</i> | Set the appropriate ITEM(s) to the new Voice Messaging DN ( <i>xxxx</i> ).          |

**Table 4-9**  
**Deleting a service DN**

| Prompt | Response | Comment                    |
|--------|----------|----------------------------|
| >      | LD 23    | Load overlay 23.           |
| REQ    | OUT      |                            |
| TYPE   | ACD      |                            |
| CUST   | _____    | Enter the customer number. |
| ACDN   | _____    | Enter the old service DN.  |

**Table 4-10**  
**Creating a new service DN**

| Prompt | Response | Comment                       |
|--------|----------|-------------------------------|
| >      | LD 23    | Load overlay 23.              |
| REQ    | NEW      |                               |
| TYPE   | ACD      |                               |
| CUST   | _____    | Enter the customer number.    |
| ACDN   | _____    | Enter the new service DN.     |
| MWC    | NO       |                               |
| MAXP   | 1        |                               |
| NCFW   | _____    | Enter the Voice Messaging DN. |

**Table 4-11**  
**Disabling a hardware location**

| Prompt | Response       | Comments                                                                                                            |
|--------|----------------|---------------------------------------------------------------------------------------------------------------------|
| >      | LD 32          | Load overlay 32.                                                                                                    |
| .      | DISU <i>cu</i> | <i>cu</i> is the Option 11 routing address for the hardware location. (Refer to "Hardware locations" on page 10-2.) |

**Table 4-12**  
**Enabling a hardware location**

| Prompt | Response       | Comments                                                                                                     |
|--------|----------------|--------------------------------------------------------------------------------------------------------------|
| >      | LD 32          | Load overlay 32.                                                                                             |
| .      | ENLU <i>cu</i> | Enter the Option 11 routing address for the hardware location. (Refer to "Hardware locations" on page 10-2.) |

**Table 4-13**  
**Changing a hardware location's DN**

| <b>Prompt</b> | <b>Response</b> | <b>Comments</b>                                                                                              |
|---------------|-----------------|--------------------------------------------------------------------------------------------------------------|
| >             | LD 11           | Load overlay 11.                                                                                             |
| REQ           | CHG             |                                                                                                              |
| TYPE          | 2008            |                                                                                                              |
| TN            | <i>c u</i>      | Enter the Option 11 routing address for the hardware location. (Refer to "Hardware locations" on page 10-2.) |
| ECHG          | YES             | For easy change.                                                                                             |
| ITEM          | KEY 1 SCN xxxx  | xxxx is the new channel DN for the hardware location.                                                        |

**Table 4-14**  
**Deleting a hardware location's DN**

| <b>Prompt</b> | <b>Response</b> | <b>Comments</b>                                                                                              |
|---------------|-----------------|--------------------------------------------------------------------------------------------------------------|
| >             | LD 11           | Load overlay 11.                                                                                             |
| REQ           | OUT             |                                                                                                              |
| TYPE          | 2008            |                                                                                                              |
| TN            | <i>c u</i>      | Enter the Option 11 routing address for the hardware location. (Refer to "Hardware locations" on page 10-2.) |

**Table 4-15**  
**Creating a hardware location DN**

| Prompt | Response        | Comments                                                                                                     |
|--------|-----------------|--------------------------------------------------------------------------------------------------------------|
| >      | LD 11           | Load overlay 11.                                                                                             |
| REQ    | OUT             |                                                                                                              |
| TYPE   | 2008            |                                                                                                              |
| TN     | <i>c u</i>      | Enter the Option 11 routing address for the hardware location. (Refer to "Hardware locations" on page 10-2.) |
| REQ    | ****            |                                                                                                              |
| KEY    | 0 ACD xxxx yyyy | xxxx is the new Voice Messaging DN and yyyy is the position ID for the hardware location.                    |
| KEY    | 1 SCN zzzz      | zzzz is the channel DN for the hardware location.                                                            |
| KEY    | 2 MSB           |                                                                                                              |
| KEY    | 3 NRD           |                                                                                                              |
| KEY    | 6 TRN           |                                                                                                              |
| KEY    | 7 AO3           | O is the letter O.                                                                                           |
| KEY    | 9 RLS           |                                                                                                              |



---

# Troubleshooting and maintenance

---

This chapter describes the procedures you can follow should anything go wrong with Meridian Mail, and the procedures you should follow to make these problems less likely.

The troubleshooting procedures assume that you are completely familiar with the Meridian Mail hardware and software installation procedures described in Chapter 1 and Chapter 3.

## Troubleshooting

For any problems with Meridian Mail you should first consult *Meridian Mail—System Event and Error Reports*. This book contains a comprehensive list of the events and errors recorded on the SEER printer. (Refer to page 5-14.)

Troubleshooting Meridian Mail hardware is a simple process of determining the component that is causing the problem and replacing it. The components cannot be repaired in the field; return them to your Northern Telecom distributor for repair.

If you are unable to isolate a problem with Meridian Mail software or hardware consult *Meridian 1 Option 11—Fault Clearing Guide*. Problems with the PBX often cause problems with Meridian Mail.

The following procedures document the problems you might encounter, and the steps you should take to solve them. The steps in each procedure are arranged from the most likely cause to the least likely cause. Eliminate each possibility, until the problem is solved.

Suppose a portion of a procedure reads as follows:

- 1 Ensure that the main Meridian 1 power supply is on.
- 2 Ensure that the Meridian Mail power switch on the 68k Card is on.
- 3 Turn off the Meridian Mail power switch on the 68k Card, and ensure that the Connector Board is properly seated.

The first three steps do not—as it first might appear—instruct you to ensure that the power is on and then to turn it off. Rather you should first ensure that the main Meridian 1 power is on. If turning it on does not clear the problem, then ensure that the Meridian Mail power switch is on. If this still does not clear the problem, only then should you proceed to step 3. In this case, it instructs you to turn off the power before touching the Connector Board.

Unless otherwise stated, an instruction that tells you to replace a component implies that you should then reinstall and restart Meridian Mail to see if the problem has cleared. If replacing the component does not clear the problem, you should reinstall the old component and proceed to the next step in the troubleshooting procedure. For example, the following procedure:

- 1 Replace the 68k Card.
- 2 Replace the DVP Card in slot MM2.
- 3 Replace the DVP Card in slot 9.
- 4 Replace the Disk/Power Supply Card.

does not instruct you to replace all of the Meridian Mail cards. Rather, you should first try replacing the 68k Card, reinstalling the rest of Meridian Mail and restarting the system. If this does not solve the problem, you should reinstall the old 68k Card and try replacing the DVP Card. If this still does not solve the problem, you should reinstall the old DVP Card and try replacing the Disk/Power Supply Card.

### Precautions

You must not remove or handle any of the Meridian Mail hardware while Meridian Mail is on and running. If the switch on the 68k Card is on, follow the procedure for stopping Meridian Mail on page 4-5. Failing to do so can result in damage to the components or injury to yourself.



**DANGER**  
**Shock hazard**

Before removing or handling any Meridian Mail hardware, ensure that the power switch on the 68k Card is in the off (down) position.

*Note:* You need not, however, turn off the power to the Meridian 1 PBX. You can safely handle Meridian Mail hardware while the switch is running, so long as the power to Meridian Mail is off.

Before touching any components, ensure that you are properly grounded by putting on the wrist strap connected to the Meridian 1 cabinet. Static electricity can irreparably damage sensitive electronic components.

**CAUTION**  
**Static electricity**

The printed circuit boards are susceptible to static damage. Before handling the PCBs take the appropriate precautions.

## Replacing components

Meridian Mail components are replaced in the opposite way to which they are installed. (Refer to the appropriate sections in Chapter 1.) The only exception to this is the removal of the Connector Board.

### Removing the Connector Board

The connections between the Connector Board and the Meridian Mail cards are too tight for you to remove the Connector Board in one step. It must, instead, be removed one card at a time.

- 1 Courtesy down Meridian Mail and turn it off. (Refer to page 4-5.)
- 2 Grasping the top lock latches with one hand and the bottom latches with the other, unlock all cards simultaneously and pull the assembly slightly out of the cabinet.
- 3 Move all the lock latches so that they are at right angles to the cards.

- 4 Push the cards back into the cabinet until stopped by the edge of the lock latches.
- 5 On the DVP Card in slot MM2, grasp the top and bottom lock latches and slowly lock it back into the cabinet.  
*The latches on the other cards prevent them from moving farther into the cabinet, and the DVP Card is pulled from the Connector Board.*
- 6 If there is a DVP card installed in slot 9, repeat step 5 on the card installed in slot 10.
- 7 Remove the leftmost card from the Connector Board.
- 8 Remove the Connector Board from the rightmost card.

### Problems at start-up

Just above the power switch on the 68k Card is a small LED. When the system is first turned on, the LED lights briefly and Meridian Mail proceeds with its internal diagnostics and start-up procedures. The LED should remain unlit during the entire process which takes approximately four minutes.

When start-up is complete, the LED lights and stays lit. A flashing LED indicates a problem with the start-up procedure.

The following procedures correspond to the different possible LED indications:

- LED does not light at start up, page 5-4.
- LED lights at start-up but does not go out, page 5-6.
- LED flashes rapidly or does not come back on after four minutes, page 5-6.
- LED flashes slowly, page 5-7.


#### LED does not light at start-up

- 1 Ensure that the main Meridian 1 power supply is on.
- 2 Ensure that the Meridian Mail power switch on the 68k Card is on.
- 3 Check the card connections, as follows:
  - a. Ensure that the Connector Board is properly seated.

- b. Ensure that the 68k Card is firmly pushed into the connector at the back of the Meridian 1 cabinet.
  - c. Ensure that none of the pins on the back connector or on the front connectors of the Meridian Mail cards are bent.
- 4 If the LED still does not light:
- a. Remove all the Meridian Mail cards.
  - b. Reinstall the 68k Card. Push it all the way to the back of the cabinet and lock the latch levers.
  - c. Plug the appropriate connector on the Connector Board into the 68k Card.
  - d. Turn on the Meridian Mail power switch on the 68k Card.
  - e. Using a voltmeter, place the positive terminal on Pin 2 of P2. Place the negative terminal on Pin 10 of P2 on the Connector Board. (Refer to Figure 5-1.) The meter should read approximately -52 volts. If it does not, the 68k Card is defective; replace it.

**Note:** On both three-card and four-card systems, P2 is the connector that plugs into the primary DVP Card. Refer to Figure 5-1.

**Figure 5-1**  
**Testing voltage and resistance on the Connector Board**



- 5 If the LED still does not light:
  - a. Remove the 68k Card with the Connector Board attached.
  - b. Using an ohmmeter, measure the resistance between Pin 19 of P2 and Pin 22 of P2 on the Connector Board. On a functional 68k Card the meter should read between 15 and 25 ohms. If it does not, then the card is defective. Replace it.
- 6 Replace the Disk/Power Supply Card but retain the disk drive; it contains the customer's Meridian Mail data.
- 7 The Connector Board is defective. Replace it.

### **LED lights at start-up but does not go out**

- 1 Ensure that you have not installed an older DVP Card (NTAK15AA) or an older C25 Card (NTAK16AA) in slot 9. These older cards only function in slot MM2.
- 2 Remove the DVP Card assemblies and reinstall Meridian Mail without them. If the LED goes out, one of the DVP Cards is defective.
  - a. Replace each DVP Card assembly individually to determine which is defective.
  - b. Replace the defective card. Retain any C25 Cards and attach them to the new DVP Card.
- 3 Replace the 68k Card.
- 4 Replace the Connector Board.

### **LED flashes rapidly or does not come back on after four minutes**

The LED flashes rapidly (approximately one second on and one second off) or does not come back on after four minutes when either the 68k Card or the SCSI diagnostics have failed.

- 1 Test the 68k Card, as follows:
  - a. Disconnect the SCSI cable to the disk drive and the SCSI cable to the tape drive, if one is connected. Remove the DVP Card assemblies and reinstall the remaining Meridian Mail hardware without them.  
*The LED should flash slowly.*
  - b. If the LED still flashes rapidly, replace the 68k Card.

- 2 Test the DVP and C25 Cards, as follows:
  - a. Reconnect the SCSI cables that were disconnected in step 1 but do not reinstall the DVP Card assemblies.
  - b. If Meridian Mail now starts correctly, one of the DVP Cards or one of the C25 Cards is defective. Reinstall each card, one at a time, until the problem reappears. Replace the defective card.
- 3 Replace the Disk/Power Supply Card but retain the disk drive; it contains the customer's Meridian Mail data.

**LED flashes slowly**

The LED flashes slowly (approximately five seconds on and five seconds off) when the software fails to load.

- 1 If a tape drive is connected, ensure that it is turned on and that its SCSI address is set to 1.
- 2 Turn the tape drive off and then on again.
- 3 Check that the power and SCSI connections from the Disk/Power Supply Card to the disk drive are properly secured and correctly oriented.
- 4 Check the Connector Board, as follows:
  - a. Remove the Connector Board and ensure that there are no bent pins on the front connectors of the Meridian Mail cards.
  - b. Reinstall the Connector Board, ensuring that it is firmly seated on all cards.
- 5 Ensure that all terminators have been removed from the disk drive, that the correct jumpers required for the model of disk drive have been installed, and that all other jumpers have been removed. Refer to Chapter 12.
- 6 If a tape drive is not connected, ensure that the external terminator on the Disk/Power Supply Card is firmly in place.
- 7 Replace the Connector Board.
- 8 Reload the Meridian Mail software from tape. (Refer to Chapter 3.)
- 9 Replace the 68k Card.

- 10 Replace the disk on the Disk/Power Supply Card and restore the system from the most recent backup tape. (Refer to page 4-9.)

### **Problems during system expansion or software upgrade**

Problems can occur while reading from the software tape and writing to the disk during storage expansion, software expansion, or software upgrade.

They may be the result of a defective tape, a defective disk, or a problem with the SCSI link between the tape drive and the disk drive.

- 1 Restore the system to its original state, as follows:
  - a. If you added a new DVP Card or any new C25 Cards, remove them.
  - b. If you installed a new disk drive, replace it with the old disk drive.
  - c. Ensure that all cable connections are secure, that the Connector Board is firmly seated, and that the Meridian Mail cards are locked firmly in place in the cabinet.
  - d. Restore the system from the back-up tape (refer to page 4-9) and attempt to start Meridian Mail. (Refer to page 4-6.)
- 2 If Meridian Mail starts, attempt the expansion or upgrade procedure again. If it fails a second time, restore the system and attempt the procedure again but with a different software tape.

or

If Meridian Mail does not start correctly, follow the trouble-shooting procedures beginning on page 5-4.
- 3 Replace the disk drive on the Disk/Power Supply Card, restore the system, and attempt the expansion or upgrade procedure again.

### **Tape drive problems**

#### **A tape is not recognized by the system**

- 1 If you are performing a restore, ensure that you have inserted the correct tape.
- 2 Ensure that you have inserted the tape correctly. (Refer to page 1-15.)
- 3 Ensure that the tape is of the correct format. (Refer to page 1-3.)
- 4 Ensure that the write protection on the tape is not set.

- 5 Turn the tape drive off and then on again.
- 6 Clean the tape drive. (Refer to page 5-15.)
- 7 Ensure that the tape drive has been correctly installed. (Refer to page 1-14.)

### The tape drive does not correctly retension a tape

- 1 Turn the tape drive off and then on again.

### Starting a backup before inserting a tape

If, while attempting to manually back up the system, you inadvertently press

**OK To Start Backup** before inserting a tape:

- 1 Insert a tape into the tape drive.  
*An error message is displayed indicating that the backup has failed.*
- 2 Press **Exit**.
- 3 Retry the backup procedure.

### Defective tape during backup

If, while attempting to manually backup the system, you insert a defective tape:

- 1 Retry the backup procedure with a different tape. If the backup is successful, discard the defective tape.
- 2 Clean the tape drive (refer to page 5-15) and attempt the backup again.
- 3 Restart the system and retry the backup procedure.

### Defective tape during restore

If, while attempting to restore the system, you are informed that the tape is defective:

- 1 Clean the tape drive (refer to page 5-15) and attempt the restore again.
- 2 If the second attempt is not successful, the tape is unusable. Do one of the following:
  - Restore from an earlier backup tape, if one is available.

**Note:** Use the most recent backup you can find. Any changes that you've made to the system since that backup will have to be recreated.

- Install a new system and redefine your users.

**Note:** This should be your last resort; and should never have to be done if you make sure to make frequent backups.

Once you have successfully restored the system:

- a. Perform a new system backup with a different tape.
- b. Discard the tape that caused the error.

### Terminal problems

Under most circumstances the Meridian Mail system should start up automatically and display the Meridian Mail logon screen on the System Administrator's terminal. You may notice problems at start-up or the terminal may become disabled during normal operation.

Auxiliary terminals (such as those used with Hospitality systems) are susceptible also to problems with the RSM Breakout Assembly and the 68k Card. First, try to clear the problem as you would with the System Administrator's terminal, then follow the steps for auxiliary terminals.

#### The terminal does not display Meridian Mail screens

- 1 The System Administrator may have inadvertently switched to the Meridian 1 PBX software. If you see the > prompt, enter **AX** **Return**.
- 2 Press **Control** ] to switch to Meridian 1 PBX software and, at the > prompt, enter **AX** **Return**.
- 3 Reset the console port (port 8) by disabling it and re-enabling it, as follows:
  - a. Follow the procedures described on page 4-3. Reset the console port only; do not reset the AML (port 9).
  - b. Enter **AX** **Return** to return to Meridian Mail.

#### The terminal displays the Meridian Mail screens incorrectly

Occasionally the connection between Meridian Mail and the System Administrator's terminal may generate extraneous characters that cause the terminal to display the Meridian Mail screens incorrectly.

To redraw the screen:



- 1 Press **Control R**.

If the screen is incorrectly displaying the lines on the Meridian Mail screens as a string of “q”s:

- 1 Press **Control W**.  
*You are presented with a small pop-up menu.*
- 2 Enter IF **Return**.  
*The screen redraws correctly.*

### **The keyboard does not respond**

- 1 If there is a printer attached to your system, ensure that the printer is ready and on line. (Refer to page 1-20, 5.)
- 2 Press **Control ]** to switch to Meridian 1 PBX software. At the > prompt, enter **AX Return**.
- 3 Reset the console port (port 8) by disabling it and re-enabling it, as follows:
  - a. Follow the procedures described on page 4-3. Reset the console port only; do not reset the AML (port 9).
  - b. Enter **AX Return** to return to Meridian Mail.
- 4 Turn the terminal off and on again.
- 5 Check the connection between the keyboard and the terminal.
- 6 Check the terminal's connection to the SDI port. (See Figure 1-3 on page 1-6.)
- 7 Ensure that the terminal settings are correct as described in “Terminal configuration” (Chapter 11).

### **Auxiliary terminal problems**

- 1 Ensure the switch on the RSM Breakout Assembly is in the Normal (left) position.
- 2 Ensure that the terminal settings are correct as described in “Terminal configuration” (Chapter 11).
- 3 Check all cable connections. (Refer to Table 8-3 on page 8-6.)

- 4 Check for any special null modem requirements.
- 5 Try the terminal on another, functioning RSM port.
- 6 Replace the RSM Breakout Assembly.
- 7 Replace the 68k Card.

### Modem problems

Handle modem problems in the same way as problems with auxiliary terminals.

### Voice mail problems

The majority of problems with voice mail are often the result of faults in one of the DVP or C25 Cards, particularly with one or more of the hardware locations. The most obvious problem you might encounter is where Meridian Mail answers the telephone properly but the caller does not hear any voice prompts. Depending on the number of defective hardware locations, this problem may occur intermittently or on all calls to Meridian Mail.

A more subtle problem occurs when a hardware location is defective in such a way that it does not even answer calls to Meridian Mail. Providing the system has other, functional hardware locations, callers may not notice this degradation in service unless they encounter a significant increase in the number of busy signals when they dial Meridian Mail.

You have access to voice card diagnostics through the System Administrator's terminal. These tests allow you to isolate the hardware location that is causing the problem.

- 1 Ensure that you have not installed an older DVP Card (NTAK15AA) or an older C25 Card (NTAK16AA) in slot 9. These older cards only function in slot MM2.
- 2 Check the card connections, as follows:
  - a. Remove the Connector Board and ensure that there are no bent pins on the front connectors of the Meridian Mail cards.
  - b. Reinstall the Connector Board, ensuring it is firmly seated on all cards.

- c. Ensure that the DVP Cards and the C25 Cards are firmly connected.

**3** Test the DVP and C25 Cards as follows:

- a. From the Meridian Mail login screen, press **Control W**.  
*You are presented with a small pop-up menu.*
- b. If you can't see the cursor on this menu, press **I**.
- c. Press **↑** and **↓** to move the cursor to "Console" and **S** to select it.  
*The terminal displays the results of the Meridian Mail diagnostics.*

**Note:**

Card 4 is the DVP Card in slot MM2.

Card 5 is the first C25 Card attached to the DVP Card in slot MM2.

Card 6 is the second C25 Card attached to the DVP Card in slot MM2.

Card 7 is the DVP Card in slot 9.

Card 8 is the first C25 Card attached to the DVP Card in slot 9.

Card 9 is the second C25 Card attached to the DVP Card in slot 9.

- d. Press **Control W** and select "MMI" to return to the Meridian Mail logon screen.
- e. Replace any cards that have not passed the diagnostics.
- f. In order to bring them back into service, you must run Out of Service Diagnostics on each of the cards you replace, as follows:
  - i. Log on to Meridian Mail.
  - ii. From the Main Menu, choose "5 System Status and Maintenance" → "2 Card Status".
  - iii. Press **Disable Card** and at the prompt enter the number of each card that you replaced.
  - iv. Press **Out Of Service Diagnostics** and enter the card numbers.
  - v. Press **Enable Card** and enter the card numbers.
- g. You must also enable the new hardware locations, as follows:
  - i. From the Card Status form, press **Exit**.
  - ii. From the System Status and Maintenance Menu, choose "3 Channel Status".

- iii. For each “Out of Service” channel, press **Enable Port** and enter the channel number.
- h. Restart Meridian Mail and repeat steps 3a through 3d to verify any new cards you’ve installed.
- 4** Replace the DVP Card in slot MM2.
- 5** Replace the DVP Card in slot 9.
- 6** Replace the 68k Card.
- 7** Replace the Meridian 1 CPU/Conf Pack. (Refer to *Meridian 1 Option 11—Installation Guide*.)

### System event and error reports (SEERs)

System event and error reports contain information about every system event and error that occurs on the Meridian Mail system. To configure Meridian Mail to print SEERs as they occur, refer to page 1-21.

To view the SEERs for a given period:

- 1** From the Main Menu on the System Administrator’s terminal, choose “5 System Status and Maintenance”→ “5 System Event and Error Reports”.
- 2** On the System Event and Error Reports form, enter the appropriate dates and times in *Report Period Start* and *Report Period End*.
- 3** Press **View Reports**.

The reports provide you with a brief description of the system event or error and when it occurred. For a more detailed description consult *Meridian Mail—System Event and Error Reports*.

### Spares planning

Table 5-1 lists the field-replaceable components of the Meridian Mail card option, the mean time between failures (MTBF), the predicted failures per million hours, and the number of spares of each item your location should stock, should you decide to stock spares.

**Table 5-1  
Spares planning**

| Component           | Code                 | MTBF<br>(years) | Failures/<br>1M hrs | Units serviced by location |    |     |     |     |
|---------------------|----------------------|-----------------|---------------------|----------------------------|----|-----|-----|-----|
|                     |                      |                 |                     | 1                          | <5 | <10 | <20 | <30 |
| Tape Drive          | (See page 1-3)       | 1.7             | 67.0                | 1                          | 3  | 4   | 5   | 5   |
| 80 Mb disk          | A0377786             | 8.0             | 14.3                | 1                          | 2  | 3   | 4   | 4   |
| 170 Mb disk         | A0378251             | 8.0             | 14.3                | 1                          | 2  | 3   | 4   | 4   |
| 300 Mb disk         | A0351371<br>A0602257 | 8.0             | 14.3                | 1                          | 2  | 3   | 4   | 4   |
| 68k Card            | NTAK14BA             | 18.0            | 6.4                 | 1                          | 2  | 3   | 4   | 4   |
| DVP Card*           | NTAK15AA/AB          | 58.0            | 2.0                 | 1                          | 2  | 2   | 3   | 3   |
| C25 Card*           | NTAK16AA/AB          | 60.0            | 2.0                 | 1                          | 2  | 2   | 3   | 3   |
| RSM Assembly        | NTAK18AA/BA          | 240.0           | 0.5                 | 1                          | 2  | 2   | 3   | 3   |
| Disk/Power Card     | NTAK13AA             | 299.0           | 0.4                 | 1                          | 2  | 2   | 3   | 3   |
| Connector Board     | NTAK17AA/BA          |                 |                     | 1                          | 2  | 2   | 3   | 3   |
| <b>Total system</b> |                      | <b>4.3</b>      |                     |                            |    |     |     |     |

*\*Some systems have more than one of these cards. When planning for spares, consider the number of hardware locations on the systems you service.*

## Maintaining the external tape drive

To ensure reliable tape drive performance, you should establish a regular cleaning schedule and observe the following precautions:

- Avoid mounting the tape drive where it is subjected to continuous shocks or vibrations.
- Maintain a clean, dust-free environment within the temperature and humidity limits listed in the specifications of the Meridian 1 option 11 system.
- Keep all liquids away from the drive and tapes to prevent spills into the equipment.
- Exercise reasonable care when using and storing tape cartridges. Do not place cartridges on the Meridian 1 cabinet or the monitor of the System Administrator's terminal.
- When a stored tape is moved to an environment with a greatly different temperature, allow the tape to slowly reach room temperature before using it.

- Do not open the cartridge access door or touch the tape.
- Keep the tape drive turned on when it is connected to Meridian Mail.

## **Cleaning the tape drive**


To clean the tape drive, you need the following supplies:

- Low pressure aerosol air.
- Tape head cleaning fluid or reagent grade chemically-pure isopropyl alcohol.
- Tape head cleaning pads, lint-free cotton swabs, or any industry-acceptable head-cleaning swabs, six inches or longer.

You should clean the head assembly after an initial pass with a new tape cartridge and after eight hours of normal use. You should clean the sensor hole and tape cartridge cavity whenever dust is visible.

- 1** If there is a tape cartridge in the tape drive, remove it.
- 2** If the power to the tape drive is on, turn it off.
- 3** Push the head loading lever to the load position.
- 4** Carefully blow out dust from the sensor hole and tape cartridge cavity with aerosol air.
- 5** Moisten a pad or swab with the head-cleaning fluid until it is saturated but not dripping.
- 6** Carefully wipe the head in the direction that the tape travels. (Refer to Figure 5-2.) Do not wipe perpendicularly or use a circular scrubbing motion.
- 7** Discard the used swab and repeat steps 5 and 6 with new swabs until the swab shows no signs of dirt.
- 8** Use a new, dry swab to remove any remaining cleaning fluid from the head.
- 9** Push the head loading lever away from the load position.
- 10** If there was a tape cartridge in the tape drive, replace it.
- 11** If the power to the tape drive was on at the start of this procedure, turn it back on.

**Figure 5-2**  
**Cleaning the tape head**







---

## Software upgrades and conversions

---

Software upgrades and conversions allow you to install new versions of the Meridian Mail software without losing the data currently stored on the disk. If, for instance, any of the DNs on the system you are upgrading have been changed from the defaults, they will not be altered by the upgrade or conversion process.

Software upgrades occur within the same release of Meridian Mail. For example, if you are running Meridian Mail release 8, you might upgrade from version 8.0 to version 8.1 and later to version 8.2. Such incremental updates are released periodically by Northern Telecom to correct problems and improve service, but they all share the same features and capabilities as the initial release of the product.

Software conversion is performed when Northern Telecom introduces a new release of Meridian Mail, with new features and new capabilities. For example, you must convert from Meridian Mail release 8 to Meridian Mail release 9, if you wish to take advantage of any of the new features available in that new release.

### What you need

- The new Meridian Mail software tape, NTAK72xE. (Refer to Table 2-1 on page 2-2 for the exact part number).
- The new keycode for your system, if applicable. (Refer to Chapter 2.)

The keycode you need is printed on the label on the box containing the Meridian Mail software tape, together with the serial number of the system. If you are responsible for more than one Meridian Mail system, ensure that you are using the correct keycode for each. If the serial number of the system does not match that on the label, the keycode will be rejected.

Unless you have also ordered additional capabilities for your system, you do not have to enter a keycode to upgrade the software.

### Precautions

If you have ordered additional capabilities for your system, you will use the same keycode to enable them after the software upgrade or conversion. You must enable them one at a time and in the following order:

- Software upgrade or conversion
- Hardware modification (Refer to page 7-2.)
- Storage expansion (Refer to page 7-3.)
- Language expansion (Refer to page 7-5.)
- Feature expansion (Refer to page 7-6.)

Failure to follow this order may cause problems with the system.

Of course, not all systems will require each of these steps—simply skip the ones you don't have to perform, but maintain the order. Don't, for instance, attempt a feature expansion before a language expansion.

### Performing a software upgrade or conversion

To perform a software upgrade or conversion:

- 1 Perform a full backup of the Meridian Mail system. (Refer to page 4-7.)
- 2 Run the System Installation and Modification Utility from the Meridian Mail software tape. (Refer to Chapter 2.)
- 3 From the System Installation and Modification Menu, choose "2 Upgrade to the latest MM9 release".

or

"3 Convert MM8 system to MM9 system".

**Note:** If your system is of an earlier release than MM-8, you must first convert from that release to MM-8 and then proceed to convert to MM-9. You can convert to MM-8 from any release labelled 1.x—1.10 or 1.12c, for example—but you must use an MM-8 software tape.

- 4 Respond to the prompts as they appear.

If you are converting from a pre-MM9 system each of your currently-installed hardware locations will be configured as full-service voice channels.

Don't worry if you respond to a prompt incorrectly. Before the final installation begins you are given another opportunity to re-enter the information.

The final upgrade takes about 45 minutes from start to finish, plus an extra 20 minutes for each additional language, after which you are prompted as follows:

```
Your system has been converted successfully.
Please remove the tape and boot into service.
```

- 5** At the prompt:
  - a. Remove the tape from the drive. (Refer to page 1-15.)
  - b. Turn off the power to Meridian Mail.
  - c. Wait ten seconds.
- 6** Start Meridian Mail. (Refer to page 4-6.)  
*The system starts up in full service.*
- 7** If, when you start Meridian Mail, the terminal displays Meridian Mail screens but the keyboard does not respond:
  - a. Press **[Control]**
  - b. Enter **AX** **[Return]** to return to Meridian Mail.

If the keyboard still does not respond, refer to "Terminal problems" on page 5-10.

If you have any other problems with this procedure, refer to "Problems during system expansion or software upgrade" on page 5-8.



---

## System expansion

---

This chapter describes the procedures to follow when adding new hardware locations or modifying the existing hardware locations, expanding the system's disk storage, adding new languages, or enabling optional features.

### What you need

- The Meridian Mail software tape, NTAk72xE. (Refer to Table 2-1 on page 2-2 for the exact part number).
- The new keycode for your system. (Refer to Chapter 2.)

System expansion is enabled through a security keycode purchased from your Meridian 1 representative. There is no need to purchase any new software.

When you wish to expand an existing system, you receive a pair of new labels from your Meridian 1 representative containing the keycode you need. Stick these labels on top of the old keycode labels, one on the tape and the other inside the door of the Option 11 cabinet.

**Note:** Do not place the label on the metal plate on the back of the tape. This area must be kept clear to allow for the discharge of electrostatic buildup in the tape.

If you order your new features along with the latest software release, the label on the new software tape will contain the keycode you need.

### Precautions

This single keycode enables each of the system modification procedures you have to perform. It is important, however, that you perform the procedures in the following order:

- Software upgrade or conversion (Refer to Chapter 6.)
- Hardware modification (Refer to page 7-2.)
- Storage expansion (Refer to page 7-3.)
- Language expansion (Refer to page 7-5.)
- Feature expansion (Refer to page 7-6.)

Failure to follow this order may cause problems with the system.

Of course, not all systems will require each of these steps—simply skip the ones you don't have to perform, but maintain the order. Don't, for instance, attempt a feature expansion before a language expansion.

### Hardware modification

Hardware modification allows you add new hardware locations to your system or modify the attributes of the existing hardware locations. The number of hardware locations dictates how many people can use Meridian Mail at the same time. The attributes dictate which services each hardware location can provide.

Before adding any DVP or C25 cards, you must ensure that the DNs reserved for the hardware locations the cards will enable have not been reassigned to some other use.

- 1 Log on to the Meridian 1 PBX. (Refer to page 4-1.)
- 2 Print a hardware location report by following the prompts in Table 4-6 on page 4-19.
- 3 Using the hardware location table on page 10-2, determine the two default channel DNs for the card you're installing.
- 4 If the values in the report are different from those in the table, you can do one of two things:
  - a. Reassign the service that is currently using the DNs. (Refer to *Meridian 1 Option 11—Administration Guide*.)
  - b. Change the hardware location DNs to DNs which are not in use by following the procedures defined in "Changing a hardware location DN" on page 4-14.

Once any conflicts have been resolved, you can add the cards, as follows:

- 1 Perform a full backup of the Meridian Mail system. (Refer to page 4-7.)
- 2 Courtesy down Meridian Mail and turn it off. (Refer to page 4-5.)
- 3 Install the new voice processor cards. (Refer to "Replacing components" on page 5-3 and "Assembling and inserting the DVP Card (NTAK15AB)" on page 1-9.)
- 4 Run the System Installation and Modification Utility from the Meridian Mail software tape. (Refer to Chapter 2.)
- 5 From the System Installation and Modification Menu, choose "5 Hardware Modification".
- 6 Respond to the prompts as they appear. (Refer to "Assigning hardware location attributes" on page 2-5.)

Don't worry if you respond to a prompt incorrectly. Before the final installation begins you are given another opportunity to re-enter the information.

The final expansion should take 30 minutes to complete, after which you are prompted as follows:

```
The operation successfully completed.
Please remove the tape and boot into service.
```

- 7 At the prompt:
  - a. Remove the tape from the drive. (Refer to page 1-15.)
  - b. Turn off the power to Meridian Mail.
  - c. Wait ten seconds.
- 8 Start Meridian Mail. (Refer to page 4-6.)  
*The system starts up in full service.*

If Meridian Mail does not start correctly, follow the trouble-shooting procedures beginning on page 5-4.

## Storage expansion

Storage expansion expands the hours of message storage on your system, and allows the system to support more users and more system languages.

## 7-4 System expansion

---

- 1 Perform a full backup of the Meridian Mail system. (Refer to page 4-7.)
- 2 Courtesy down Meridian Mail and turn it off. (Refer to page 4-5.)
- 3 If you need to expand the storage capacity of the system beyond that of the current disk drive:
  - a. Replace the disk drive with a new, larger disk drive. (Refer to "Replacing components" on page 5-3 and "Assembling and inserting the Disk/Power Supply Card (NTAK13AA)" on page 1-11.)
  - b. Restore the system from the backup you created in step 1. (Refer to page 4-9.)
  - c. Courtesy down Meridian Mail and turn it off. (Refer to page 4-5.)
- 4 Run the System Installation and Modification Utility from the Meridian Mail software tape. (Refer to Chapter 2.)
- 5 From the System Installation and Modification Menu, choose "6 Storage Expansion".
- 6 Respond to the prompts as they appear.

Don't worry if you respond to a prompt incorrectly. Before the final installation begins you are given another opportunity to re-enter the information.

The final expansion should take 30 minutes to complete, after which you are prompted as follows:

```
The operation successfully completed.
Please remove the tape and boot into service.
```
- 7 At the prompt:
  - a. Remove the tape from the drive. (Refer to page 1-15.)
  - b. Turn off the power to Meridian Mail.
  - c. Wait ten seconds.
- 8 Start Meridian Mail. (Refer to page 4-6.)

*The system starts up in full service.*



If you have any problems with this procedure, refer to “Problems during system expansion or software upgrade” on page 5-8.

## Language expansion

Software tapes are available containing the standard Meridian Mail voice prompts in many different languages. (Refer to Table 2-1 on page 2-2.) Each new language you add to a system requires approximately 1.25 hours of voice space on the Meridian Mail disk. You cannot add a language if voice space will be reduced to less than two hours.

- 1 Perform a full backup of the Meridian Mail system. (Refer to page 4-7.)
- 2 Run the System Installation and Modification Utility from the Meridian Mail software tape. (Refer to Chapter 2.)
- 3 From the System Installation and Modification Menu, choose “7 Language Expansion”.
- 4 Respond to the prompts as they appear.

You should be prepared to supply the feature keycodes from the system’s label and to choose the languages you require from the software tapes you received.

Don’t worry if you respond to a prompt incorrectly. Before the final expansion begins you are given another opportunity to re-enter the information.

Language expansion takes approximately 30 minutes for the first language plus 20 minutes for each additional language. Be prepared to insert any additional language tapes as the system requests them. After the final language has been loaded, you are prompted as follows:

```
The operation successfully completed.
Please remove the tape and boot into service.
```

- 5 At the prompt:
  - a. Remove the tape from the drive. (Refer to page 1-15.)
  - b. Turn off the power to Meridian Mail.
  - c. Wait ten seconds.

- 6 Start Meridian Mail. (Refer to page 4-6.)  
*The system starts up in full service with the new languages installed. The operation of multi-language systems is discussed in Meridian Mail—System Administration Guide.*
- 7 If, when you start Meridian Mail, the terminal displays Meridian Mail screens but the keyboard does not respond:
  - a. Press **[Control]** ]
  - b. Enter **AX** **[Return]** to return to Meridian Mail.

If the keyboard still does not respond, refer to “Terminal problems” on page 5-10.

If you have any other problems with this procedure, refer to “Problems during system expansion or software upgrade” on page 5-8.

## Feature expansion

Optional features on the Meridian Mail card option system include the following:

- AMIS Networking
- Bilingual prompting
- Fax on Demand
- Hospitality Voice Services
- Meridian Forms
- Meridian Mail Networking
- Multi-customer
- Network Message Service
- Outcalling

To enable one or more of these features:

- 1 Perform a full backup of the Meridian Mail system. (Refer to page 4-7.)
- 2 Run the System Installation and Modification Utility from the Meridian Mail software tape. (Refer to Chapter 2.)
- 3 From the System Installation and Modification Menu, choose “4 Feature Expansion”.

- 4 Respond to the prompts as they appear. Depending on the optional features you're enabling, you should be prepared to supply the following values for the system:

- The feature keycode from the system's label.
- The data port locations.

*Card option systems can have up to six data ports: the first two are reserved for the system administration terminal and the link to the Meridian 1 switch, the remaining four are the four ports available on the RSM card, if one is installed. The following are the recommended settings for these ports:*

| Location                     | Basic System | Hospitality System | Networked Systems | Networked Hospitality System |
|------------------------------|--------------|--------------------|-------------------|------------------------------|
| Node 1, Card 1, Port 1       | Console      | Console            | Console           | Console                      |
| Node 1, Card 1, Port 2       | CSL1 (AML)   | CSL1 (AML)         | CSL1 (AML)        | CSL1 (AML)                   |
| Node 1, Card 3 (RSM), Port 1 | Modem        | GAC                | Modem             | GAC                          |
| Node 1, Card 3 (RSM), Port 2 | Printer      | GAC (optional)     | Printer           | Modem                        |
| Node 1, Card 3 (RSM), Port 3 | Printer      | PMS                | Printer           | PMS                          |
| Node 1, Card 3 (RSM), Port 4 | Printer      | PMS                | Printer           | PMS                          |

*The port locations you define here must match the connections you make to the RSM card. The wiring diagrams for hospitality systems (Figure 8-1 on page 8-3) and networked systems (Figure 9-1 on page 9-2) are based on these recommended values. If you customize the port locations, ensure that you change the wiring accordingly.*

Don't worry if you respond to a prompt incorrectly. Before the final expansion begins you are given another opportunity to re-enter the information.

The final expansion takes about 45 minutes from start to finish, plus an extra 20 minutes for each additional language. Be prepared to insert any additional language tapes as the system requests them. After the final language has been loaded, you are prompted as follows:

The operation successfully completed.  
Please remove the tape and boot into service.

- 5 At the prompt:
- a. Remove the tape from the drive. (Refer to page 1-16.)
  - b. Turn off the power to Meridian Mail.
  - c. Wait ten seconds.

- 6 Start Meridian Mail. (Refer to page 4-6.)  
*The system starts up in full service with the defaults defined in Chapter 10.*
- 7 If, when you start Meridian Mail, the terminal displays Meridian Mail screens but the keyboard does not respond:
  - a. Press **Control ]**
  - b. Enter **AX** **Return** to return to Meridian Mail.

If the keyboard still does not respond, refer to “Terminal problems” on page 5-10.

If you have any other problems with this procedure, refer to “Problems during system expansion or software upgrade” on page 5-8.

---

## Hospitality systems

---

Meridian Mail's Hospitality Voice Services (HVS) option is used by hotels to offer voice messaging services to their staff and guests. It is designed to work with a hotel's Property Management System (PMS). This chapter describes the additional hardware installation and software procedures required in order to take advantage of Meridian Mail's HVS capabilities. The Meridian 1 PBX may or may not already be connected to a PMS.

For complete instructions on installing an HVS system, refer to *Meridian Mail Modular Option—Installation Procedures*.

### Hardware installation

The HVS Hardware Kit (NTAK35AA/A0388201) contains the following:

- 1 RSM Breakout Assembly (NTAK18AA/BA)
- 1 25 pair MDF Voice Cable, 10 feet, male to male (NE-B25C-FS)
- 1 25 pair MDF Voice Cable, 10 feet, male to bare wire (NE-A25C-FS)
- 1 DB25 peripheral cable, 10 feet, male to bare wire (NTAK37AA)
- 3 DB25 peripheral cables, 10 feet, female to bare wire (NTAK36AA)
- 1 DB25 Gender changer, female to female (A0351509)

The following are optional:

- VT420 Video display terminal (A0376839)
- HP700/32 Video display terminal (A0376518—amber)  
HP700/32 Video display terminal (A0376519—green)  
HP700/32 Video display terminal (A0376520—white)

Figure 8-1 on page 8-3 shows the basic cabling plan for hospitality systems.

## **The multiport cable**

To install the multiport cable, refer to *Meridian 1 Option 11—Installation Guide*.

## **The RSM Breakout Assembly**

Refer to page 1-5 for the RSM Breakout Assembly installation instructions.

On the RSM Breakout Assembly is an LED which, when lit, indicates that the Meridian Mail is functioning properly and communicating with the customer's PMS. When Meridian Mail is off or not functioning correctly, the RSM Breakout Assembly automatically bypasses Meridian Mail and allows the PMS and the Meridian 1 PBX to communicate directly. Below the LED is a switch that allows you to manually bypass Meridian Mail.

As seen in Figure 8-1 on page 8-3, from the RSM Breakout Assembly you can run one of two voice cables: a male to male or a male to bare wire. The male to male voice cable connects the RSM Breakout Assembly to a BIX Pack. The male to bare wire voice cable must be wired to a BIX or similar modular distribution frame according to the instructions in the tables on the following pages.

## **The hotel's property management system**

Which instructions you use to wire the hotel's PMS to the BIX pack depends on how the PMS is configured. Refer to the documentation for the product.

For DTE configurations use Table 8-1 on page 8-4.

For DCE configurations use Table 8-2 on page 8-5.

In each table, the columns on the left are for the wires from the MDF cable, and the columns on the right are for the SDI and PMS cables.

For cables exceeding 50ft in length, short haul modems are required. Inmac asynchronous line drivers (#8125) are recommended.

## **The guest administration consoles (GACs)**


To install the guest administration consoles, follow the wiring instructions in Table 8-3 on page 8-6. The columns on the left are for the wires from the MDF cable, and the columns on the right are for the wires to the consoles.

Configure the consoles according to the instructions in Chapter 11.

## Software installation

You can only enable the Meridian Mail HVS feature during software installation. You cannot add HVS to an existing system without reinstalling the software.

**Figure 8-1**  
**Hospitality system cables**



## Hospitality system administration

For more information on the set up and administration of a Meridian Mail hospitality system, consult: *Meridian Mail—System Administration Guide (Hospitality)*.

**Table 8-1**  
**Wiring for DTE PMS systems**

| Pair No | Colors | BIX Pos# | Cable | Colors | DB25 Pin# | Signal |
|---------|--------|----------|-------|--------|-----------|--------|
| 1       | WH/BL  | 1        | SDI   | RD/BK  | 8         | DCD4   |
|         | BL/WH  | 2        | -     | -      | -         | -      |
| 2       | WH/OR  | 3        | SDI   | WH/BK  | 6         | DSR4   |
|         | OR/WH  | 4        | SDI   | BK     | 20        | DTR4   |
| 3       | WH/GR  | 5        | SDI   | BL     | 5         | CTS4   |
|         | GR/WH  | 6        | SDI   | OR     | 4         | RTS4   |
| 4       | WH/BR  | 7        | SDI   | RD     | 3         | RXD4   |
|         | BR/WH  | 8        | SDI   | WH     | 2         | TXD4   |
| 5       | WH/SL  | 9        | -     | -      | -         | -      |
|         | SL/WH  | 10       | SDI   | GR     | 7         | SG     |
| 6       | RD/BL  | 11       | -     | -      | -         | -      |
|         | BL/RD  | 12       | SDI   | SHLD   | 1         | FG     |
| 7       | RD/OR  | 13       | PMS   | RD/BK  | 8         | DCD3   |
|         | OR/RD  | 14       | -     | -      | -         | -      |
| 8       | RD/GR  | 15       | PMS   | WH/BK  | 6         | DSR3   |
|         | GR/RD  | 16       | PMS   | BK     | 20        | DTR3   |
| 9       | RD/BR  | 17       | PMS   | BL     | 5         | CTS3   |
|         | BR/RD  | 18       | PMS   | OR     | 4         | RTS3   |
| 10      | RD/SL  | 19       | PMS   | RD     | 3         | RXD3   |
|         | SL/RD  | 20       | PMS   | WH     | 2         | TXD3   |
| 11      | BK/BL  | 21       | -     | -      | -         | -      |
|         | BL/BK  | 22       | PMS   | GR     | 7         | SG     |
| 12      | BK/OR  | 23       | -     | -      | -         | -      |
|         | OR/BK  | 24       | PMS   | SHLD   | 1         | FG     |



**Table 8-2**  
**Wiring for DCE PMS systems**

| Pair No | Colors | BIX Pos# | Cable | Colors | DB25 Pin# | Signal |
|---------|--------|----------|-------|--------|-----------|--------|
| 1       | WH/BL  | 1        | SDI   | RD/BK  | 8         | DCD4   |
|         | BL/WH  | 2        | -     | -      | -         | -      |
| 2       | WH/OR  | 3        | SDI   | BK     | 20        | DSR4   |
|         | OR/WH  | 4        | SDI   | WH/BK  | 6         | DTR4   |
| 3       | WH/GR  | 5        | SDI   | OR     | 4         | CTS4   |
|         | GR/WH  | 6        | SDI   | BL     | 5         | RTS4   |
| 4       | WH/BR  | 7        | SDI   | WH     | 2         | RXD4   |
|         | BR/WH  | 8        | SDI   | RD     | 3         | TXD4   |
| 5       | WH/SL  | 9        | -     | -      | -         | -      |
|         | SL/WH  | 10       | SDI   | GR     | 7         | SG     |
| 6       | RD/BL  | 11       | -     | -      | -         | -      |
|         | BL/RD  | 12       | SDI   | SHLD   | 1         | FG     |
| 7       | RD/OR  | 13       | PMS   | RD/BK  | 8         | DCD3   |
|         | OR/RD  | 14       | -     | -      | -         | -      |
| 8       | RD/GR  | 15       | PMS   | BK     | 20        | DSR3   |
|         | GR/RD  | 16       | PMS   | WH/BK  | 6         | DTR3   |
| 9       | RD/BR  | 17       | PMS   | OR     | 4         | CTS3   |
|         | BR/RD  | 18       | PMS   | BL     | 5         | RTS3   |
| 10      | RD/SL  | 19       | PMS   | WH     | 2         | RXD3   |
|         | SL/RD  | 20       | PMS   | RD     | 3         | TXD3   |
| 11      | BK/BL  | 21       | -     | -      | -         | -      |
|         | BL/BK  | 22       | PMS   | GR     | 7         | SG     |
| 12      | BK/OR  | 23       | -     | -      | -         | -      |
|         | OR/BK  | 24       | PMS   | SHLD   | 1         | FG     |

**Table 8-3**  
**Wiring for guest administration terminals (GACs)**

| Pair No | Colors | BIX Pos# | Cable | Colors | DB25 Pin# | Signal |
|---------|--------|----------|-------|--------|-----------|--------|
| 13      | BK/GR  | 25       | GAC2  | OR/BK  | 17        | RXC2   |
|         | GR/BK  | 26       | GAC2  | GR/BK  | 15        | TXC2   |
| 14      | BK/BR  | 27       | GAC2  | RD/BK  | 8         | DCD2   |
|         | BR/BK  | 28       | GAC2  | BK     | 20        | DTR2   |
| 15      | BK/SL  | 29       | GAC2  | WH/BK  | 6         | DSR2   |
|         | SL/BK  | 30       | GAC2  | OR     | 4         | RTS2   |
| 16      | YE/BL  | 31       | GAC2  | BL     | 5         | CTS2   |
|         | BL/YE  | 32       | GAC2  | WH     | 2         | TXD2   |
| 17      | YE/OR  | 33       | GAC2  | RD     | 3         | RXD2   |
|         | OR/YE  | 34       | GAC2  | GR     | 7         | SG     |
| 18      | YE/GR  | 35       | GAC2  | BL/BK  | 22        | RI     |
|         | GR/YE  | 36       | GAC2  | SHLD   | 1         | FG     |
| 19      | YE/BR  | 37       | GAC1  | OR/BK  | 17        | RXC1   |
|         | BR/YE  | 38       | -     | -      | -         | -      |
| 20      | YE/SL  | 39       | GAC1  | RD/BK  | 8         | DCD1   |
|         | SL/YE  | 40       | GAC1  | GR/BK  | 15        | TXC1   |
| 21      | VI/BL  | 41       | GAC1  | WH/BK  | 6         | DSR1   |
|         | BL/VI  | 42       | GAC1  | BK     | 20        | DTR1   |
| 22      | VI/OR  | 43       | GAC1  | BL     | 5         | CTS1   |
|         | OR/VI  | 44       | GAC1  | OR     | 4         | RTS1   |
| 23      | VI/GR  | 45       | GAC1  | RD     | 3         | RXD1   |
|         | GR/VI  | 46       | GAC1  | WH     | 2         | TXD1   |
| 24      | VI/BR  | 47       | -     | -      | -         | -      |
|         | BR/VI  | 48       | GAC1  | GR     | 7         | SG     |
| 25      | VI/SL  | 49       | -     | -      | -         | -      |
|         | SL/VI  | 50       | GAC1  | SHLD   | 1         | FG     |

---

## Networked systems

---

This chapter describes the additional hardware installation and software procedures required in order to take advantage of Meridian Mail's networking capabilities.

For complete instructions on installing an Networking system, refer to *Meridian Mail Networking—Installation guide*.

### Hardware installation

The Networking Hardware Kit (NTAK40AA/A0388206) contains the following:

- 1 RSM Breakout Assembly (NTAK18AA/BA)
- 1 25 pair MDF Voice Cable, 10 feet, male to male (NEA25D-DE)
- 1 25 pair MDF Voice Cable, 10 feet, male to bare wire (NEA25D-SE)
- 1 DB25 peripheral cable, 10 feet, male to bare wire (NTAK37AA)
- 1 Modem (NT3M50AF)

Figure 9-1 on page 9-2 shows the basic cabling plan for networked systems.

### The RSM Breakout Assembly


Refer to page 1-5 for the RSM Breakout Assembly installation instructions.

As seen in Figure 9-1, from the RSM Breakout Assembly you can run one of two voice cables: a male to male or a male to bare wire. The male to male voice cable connects the RSM Breakout Assembly to a BIX Pack. The male to bare wire voice cable must be wired to a BIX or similar modular distribution frame according to the instructions in the Table 9-1 on page 9-2.

In Table 9-1, the columns on the left are for the wires from the MDF cable, and the columns on the right are for the male DB25 cable that connects to the

modem. Before you attach this cable to the modem, however, the modem must be correctly configured.

**Figure 9-1**  
**Networked system cables**



**Table 9-1**  
**Wiring for networked systems**

| Pair No | Colors | BIX Pos# | Cable | Colors | DB25 Pin# | Signal |
|---------|--------|----------|-------|--------|-----------|--------|
| 7       | RD/OR  | 13       | Modem | RD/BK  | 8         | DCD3   |
|         | OR/RD  | 14       |       | -      | -         | -      |
| 8       | RD/GR  | 15       | Modem | WH/BK  | 6         | DSR3   |
|         | GR/RD  | 16       | Modem | BK     | 20        | DTR3   |
| 9       | RD/BR  | 17       | Modem | BL     | 5         | CTS3   |
|         | BR/RD  | 18       | Modem | OR     | 4         | RTS3   |
| 10      | RD/SL  | 19       | Modem | RD     | 3         | RXD3   |
|         | SL/RD  | 20       | Modem | WH     | 2         | TXD3   |
| 11      | BK/BL  | 21       | -     | -      | -         | -      |
|         | BL/BK  | 22       | Modem | GR     | 7         | SG     |
| 12      | BK/OR  | 23       | -     | -      | -         | -      |
|         | OR/BK  | 24       | Modem | SHLD   | 1         | FG     |

## Configuring the modem

The following procedure assumes that you are configuring the Ven-Tel modem supported by Northern Telecom. If your modem is not a Ven-Tel modem, refer to the modem's manual and configure it to correspond to the following settings.

- 1 Connect a properly configured System Administrator's terminal directly to the modem in order to enter and verify its configuration. Use an RS-232 cable (NT3M20AQ).
- 2 Ensure that the switch labeled "SW2" on the circuit board is configured as follows:

| Switch | Position | Description                                                                                                                                                                                               |
|--------|----------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| S2-1   | Off      | Follows DTR status.                                                                                                                                                                                       |
| S2-2   | Off      | Enables word result codes for AT commands.                                                                                                                                                                |
| S2-3   | On       | Enables generation of AT command result codes.                                                                                                                                                            |
| S2-4   | On       | Disables AT command echo from modem.                                                                                                                                                                      |
| S2-5   | On       | Disables modem auto answer. If not disabled, the modem will answer phone calls in receiver mode.                                                                                                          |
| S2-6   | Off      | Carrier detect responds to carrier.                                                                                                                                                                       |
| S2-7   | On       | Speaker control may be on or off. During installation it is recommended that the speaker be on in order to hear the operation of the modem. After verifying the operation, the speaker may be turned off. |
| S2-8   | On       | The modem will respond to AT commands.                                                                                                                                                                    |
| S2-9   | Off      | The Ven-Tel NVRAM mode command set is disabled.                                                                                                                                                           |
| S2-10  | Off      | The Ven-Tel dialer feature is disabled.                                                                                                                                                                   |

**Note:** Older versions of the Ven-Tel modem may have another switch labelled "SW3." It should have all its switches set to the off position. See your Ven-Tel user's manual for the location of these switches.

- 3 Plug the modem and terminal into an appropriate AC receptacle and turn them on.
- 4 Enter **at&f**  to reset the model to the factory default values.  
*The screen displays "OK."*
- 5 Enter **at&d3**  to enable DTR-initiated reset.  
*The screen displays "OK."*
- 6 Enter **at&w**  to save the configuration.  
*The screen displays "OK."*
- 7 Turn the modem off, wait ten seconds, and turn the modem on again.
- 8 Enter **atls**  to verify the modem settings.  
*They should read as follows:*

For EC2400-33 Rev. 5.2:

```
\A0, %A0, B0, &C1, \C0, %C1, &D3, \D0, E0, F1, &G0, \G0, \J0,
&L0, M1, &M0, \N1, &P0, Q0, \Q0, &R0, \T0, &T4, V1, \V0, X4,
&X0, \X0, Y0
```

For EC2400-33 Rev. 6.0:

```
\A0, %A0, B0, &C1, \C0, %C1, &D3, \D0, E0, F1, &G0, \G0, \J0,
&L0, M1, &M0, \N1, &P0, Q0, \Q0, &R0, \T0, &T4, V1, \V0, X4,
&X0, \X0, Y0, *N0
```

For EC2400 Plus II Rev.4.53:

```
\A0, %A0, B0, &C1, \C0, %C1, &D3, \D0, E0, F1, &G0, \G0, \J0,
&L0, M1, &M0, \N1, &P0, Q0, \Q0, &R0, \T0, &T4, V1, \V0, X4,
&X0, \X0, Y0, *N0, #S0, #R0, *B0
```

If there are any discrepancies, verify the switch settings from step 2 and repeat steps 4 to 8.

- 9 Turn off the modem and connect it to the Meridian 1 system according to the instructions starting on page 9-1.
- 10 Turn off the terminal and reconnect it to the Meridian 1 PBX.

## Software installation

You can enable the Meridian Mail network option in one of two ways.

### During initial software installation

The feature is automatically enabled by entering a valid keycode.

### After initial software installation

Refer to “Feature expansion” on page 7-6.

## Network system administration

For more information on the set up and administration of a networked Meridian Mail system consult: *Meridian Mail—System Administration Guide*.





---

# Meridian Mail defaults

---

This chapter lists the default passwords and system parameters on a Meridian Mail Card Option system. Some of the values listed here are predefined, and some—such as the Voice Service DNs—can be defined automatically during software installation.

Should you choose to configure any of these parameters manually, use the defaults listed here as the basis for your custom values.

## Basic systems

### Passwords

Meridian 1 Representative's PBX password: 0000 (four zeros)

System Administrator's terminal password: adminpwd

System Administrator's Meridian 1 PBX password: MMAIL (uppercase)

The System Administrator's PBX password allows access only to overlay 2 and overlay 48. (Overlay 2 allows the Administrator to set time and date. Overlay 48 allows the Administrator to reset the console and AML data ports.)

### Geographical location

United States (32k DSP package, mu-law, no AGC, no silence compression).

### Primary language

American English, no secondary language.

### Number of users:

The number of users you can add to a system depends on the size of the disk drive, the number of languages installed, and the size of the each user's voice

mailbox. The mailbox of the first user is defined during software installation and may be 2000, 2100, or 2200.

40Mb disk: 48 users recommended.

80Mb disk: 96 users recommended.

170Mb disk and larger: 192 users recommended.

**Service DNs**

Voice messaging (Meridian Mail): 7000

Automated attendant: 7001

Express messaging: 7002

Prompt Maintenance: 7003, password 7003

**Table 10-1  
Hardware locations**

| Card           | Option 11 routing address (c u) | Mail port location | Routing address | Primary DN | Channel DN (SCN) | Position ID | Types of service |
|----------------|---------------------------------|--------------------|-----------------|------------|------------------|-------------|------------------|
| DVP in MM2     | 10 00                           | 01-4-01            | 008-0-02-00     | 7000       | 7800             | 7830        | ALL              |
|                | 10 08                           | 01-4-02            | 008-0-02-08     | 7000       | 7801             | 7831        | ALL              |
| 1st C25 in MM2 | 10 01                           | 01-5-01            | 008-0-02-01     | 7000       | 7802             | 7832        | ALL              |
|                | 10 09                           | 01-5-02            | 008-0-02-09     | 7000       | 7803             | 7833        | ALL              |
| 2nd C25 in MM2 | 10 02                           | 01-6-01            | 008-0-02-02     | 7000       | 7804             | 7834        | ALL              |
|                | 10 10                           | 01-6-02            | 008-0-02-10     | 7000       | 7805             | 7835        | ALL              |
| DVP in 9       | 10 03                           | 01-7-01            | 008-0-02-03     | 7000       | 7806             | 7836        | ALL              |
|                | 10 11                           | 01-7-02            | 008-0-02-11     | 7000       | 7807             | 7837        | ALL              |
| 1st C25 in 9   | 10 04                           | 01-8-01            | 008-0-02-04     | 7000       | 7808             | 7838        | ALL              |
|                | 10 12                           | 01-8-02            | 008-0-02-12     | 7000       | 7809             | 7839        | ALL              |
| 2nd C25 in 9   | 10 05                           | 01-9-01            | 008-0-02-05     | 7000       | 7810             | 7840        | ALL              |
|                | 10 13                           | 01-9-02            | 008-0-02-13     | 7000       | 7811             | 7841        | ALL              |

Option 11 switches come with these hardware locations correctly configured. Should you ever need to completely redefine a hardware location, respond to following prompts in Overlay 11. (Refer to Table 4-6 on page 4-19.)

**Table 10-2**  
**Hardware location parameters for Overlay 11**

| Prompt | Response        | Comment                                                                                   |
|--------|-----------------|-------------------------------------------------------------------------------------------|
| KEY    | 0 ACD xxxx yyyy | xxxx is the new Voice Messaging DN and yyyy is the position ID for the hardware location. |
| KEY    | 1 SCN zzzz      | zzzz is the channel DN for the hardware location.                                         |
| KEY    | 2 MSB           |                                                                                           |
| KEY    | 3 NRD           |                                                                                           |
| KEY    | 6 TRN           |                                                                                           |
| KEY    | 7 AO3           | O is the letter O.                                                                        |
| KEY    | 9 RLS           |                                                                                           |

## Hospitality system service DNs

The defaults for a hospitality system are the same as those for a basic system except for the service DNs, which are defined as follows:

Guest messaging: 7000

Express messaging: 7001

Hotel menu: 7002

Published numbers: 7003

Post checkout: 7004

Staff messaging: 7005

## Networked systems

The defaults for a networked system are the same as those for a basic system.



---

# Terminal configuration

---

The procedures on the following pages describe how to set up the video display terminals supported by Northern Telecom.

- NT220 terminals page 11-1
- VT220, VT320, and VT420 terminals page 11-3
- HP700/22 terminals page 11-8
- HP700/32 terminals page 11-9

If the terminal you are configuring is different from these, use the most similar settings available and follow the instructions in the manual that came with the terminal.



## **CAUTION** **Potential data loss**

Set-up mode can be entered at any time, but it is recommended that you do not do so while information is being printed on the screen.

## NT220 terminals

Table 11-1 on page 11-3 contains the set-up values for NT220 terminals. The set-up procedure is as follows:

- 1 Turn on the terminal.
- 2 Press **Setup** to enter set-up mode.  
*The current set-up values are displayed on a series of screens.*

## 11-2 Terminal configuration

---

- 3 Using the following procedures, change the values on each screen to match the values in Table 11-1.

To move through the set-up screens:

- a. Use the arrow keys to move to *To Next Set-Up Screen* and press .

To change the value in a field:

- a. Use the arrow keys to move to that field.
- b. Press  to move through the available values for that field.

- 4 When you've finished, press  again.

**Table 11-1**  
**NT220 set-up values**

|                                                                                                                                                                                                                                                                                         |                                                                                                                                                                                                                                                                                                                                                                                                                                       |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p><b>General Set-up</b><br/>           Online<br/>           Refresh Rate=60 Hz<br/>           VT200 Mode, 7-bit Controls<br/>           User Defined Keys Unlocked<br/>           User Features Unlocked</p>                                                                          | <p>Application Keypad<br/>           Normal Cursor Keys<br/>           No New Line<br/>           Set-Up=English<br/>           North American Keyboard</p>                                                                                                                                                                                                                                                                           |
| <p><b>Printer Comm. Set-Up</b><br/>           Speed=9600<br/>           Normal Print Mode<br/>           8bits, No Parity<br/>           1 Stop bit<br/>           Print Full Page<br/>           Print National Only<br/>           No Terminator<br/>           Bidirectional Off</p> | <p><b>Host Comm. Set-Up</b><br/>           Transmit=1200 <i>(for Sys. Admin. terminal)</i><br/>                             =2400 <i>(for Auxiliary terminals)</i><br/>           Receive=Transmit<br/>           Xoff at 64<br/>           8bits, No Parity<br/>           1 Stop Bit<br/>           No Local Echo<br/>           EIA Port, Data Leads Only<br/>           Disconnect, 2 s Delay<br/>           Limited Transmit</p> |
| <p><b>Display Set-Up</b><br/>           80 Columns<br/>           Interpret Controls<br/>           Auto Wrap<br/>           Jump Scroll<br/>           Light Text, Dark Screen<br/>           Cursor<br/>           Block Style Cursor<br/>           25 Lines</p>                     | <p><b>Keyboard Set-up</b><br/>           Typewriter Keys<br/>           Caps Lock<br/>           Auto Repeat<br/>           Keyclick<br/>           Margin Bell<br/>           Warning Bell<br/>           Break<br/>           Multinational<br/>           DEL=DEL; Shift/DEL=BS</p>                                                                                                                                                |
| <p><b>Answerback/Tab Set-Up</b><br/>           No Auto Answerback<br/> <i>Not Concealed</i><br/>           Answerback=<br/> <i>Leave Tabs at the default values</i></p>                                                                                                                 | <p><b>Enhance/Block Mode Set-Up</b><br/> <i>Leave these fields at the default values</i></p>                                                                                                                                                                                                                                                                                                                                          |

## VT220, VT320, and VT420 terminals

Table 11-2 on page 11-5 contains the set-up values for VT220 terminals.

Table 11-3 on page 11-6 contains the set-up values for VT320 terminals.

Table 11-4 on page 11-7 contains the set-up values for VT420 terminals. The set-up procedure is the same for all three terminals:

- 1 Turn on the terminal.
- 2 Press **Setup** to enter set-up mode.  
*The current set-up values are displayed on a series of screens.*
- 3 Using the following procedures, change the values on each screen to match the values in the appropriate table.

## 11-4 Terminal configuration

---

To move to a particular screen from the main set-up screen:

- a. Use the arrow keys to move through the menu of set-up screens and press **Enter**.

To move to the next set-up screen:

- a. Use the arrow keys to move to *To Next Set-Up* and press **Enter**.

To change the value in a field:

- a. Use the arrow keys to move to that field.
- b. Press **Enter** to move through the available values for that field.

- 4 When you've finished, press **Setup** again.



**Table 11-2**  
**VT220 set-up values**

|                                                 |                         |
|-------------------------------------------------|-------------------------|
| <b>Set-Up Directory</b>                         |                         |
| On Line                                         |                         |
| <b>Display Set-Up</b>                           |                         |
| 80 Columns                                      | Light Text, Dark Screen |
| Interpret Controls                              | Cursor                  |
| Auto Wrap                                       | Block Style Cursor      |
| Jump Scroll                                     |                         |
| <b>General Set-up</b>                           |                         |
| VT200 Mode, 7-bit Controls                      | Application Keypad      |
| User Defined Keys Unlocked                      | Normal Cursor Keys      |
| User Features Unlocked                          | No New Line             |
| Multinational                                   |                         |
| <b>Communications Set-Up</b>                    |                         |
| Transmit=1200 <i>(for Sys. Admin. terminal)</i> | 1 Stop Bit              |
| =2400 <i>(for Auxiliary terminals)</i>          | No Local Echo           |
| Receive=Transmit                                | Data Leads Only         |
| Xoff at 64                                      | Disconnect, 2 s Delay   |
| 8bits, No Parity                                | Limited Transmit        |
| <b>Printer Set-Up</b>                           |                         |
| Speed=9600                                      | Print Full Page         |
| Normal Print Mode                               | Print National Only     |
| 8bits, No Parity                                | No Terminator           |
| 1 Stop bit                                      |                         |
| <b>Keyboard Set-up</b>                          |                         |
| Typewriter Keys                                 | Warning Bell            |
| Caps Lock                                       | Break                   |
| Auto Repeat                                     | Answerback=             |
| Keyclick                                        | Not Concealed           |
| Margin Bell                                     |                         |
| <b>Tab Set-Up</b>                               |                         |
| <i>Leave this screen at the default values</i>  |                         |

**Table 11-3**  
**VT320 set-up values**

|                                                 |                               |
|-------------------------------------------------|-------------------------------|
| <b>Global Set-Up</b>                            |                               |
| On Line                                         | Comm1=RS232                   |
| Sessions on Comm1                               | 70Hz                          |
| CRT Saver                                       | Printer Shared                |
| <b>Display Set-Up</b>                           |                               |
| 80 Columns                                      | Light Text, Dark Screen       |
| Interpret Controls                              | Cursor                        |
| Auto Wrap                                       | Block Style Cursor            |
| Jump Scroll                                     | No Status Display             |
| <b>General Set-up</b>                           |                               |
| VT200 ID Mode, 7-bit Controls                   | Normal Cursor Keys            |
| User Defined Keys Unlocked                      | No New Line                   |
| User Features Unlocked                          | UPSS DEC Supplemental         |
| Application Keypad                              |                               |
| <b>Communications Set-Up</b>                    |                               |
| Transmit=1200 <i>(for Sys. Admin. terminal)</i> | No Local Echo                 |
| =2400 <i>(for Auxiliary terminals)</i>          | DEC-423, Data Leads Only      |
| Receive=Transmit                                | Limited Transmit              |
| Xoff at 64                                      | No Auto Answerback            |
| 8bits, No Parity                                | Answerback=                   |
| 1 Stop Bit                                      | Not Concealed                 |
| <b>Printer Set-Up</b>                           |                               |
| Speed=9600                                      | 1 Stop bit                    |
| No printer to Host                              | Print Full Page               |
| Normal Print Mode                               | Print National Only           |
| XOFF                                            | No Terminator                 |
| 8bits, No Parity                                |                               |
| <b>Keyboard Set-up</b>                          |                               |
| Caps Lock                                       | Break                         |
| Auto Repeat                                     | Compose                       |
| Keyclick                                        | <X> Delete                    |
| Margin Bell                                     | ., and .. Keys Send ,< and .> |
| Warning Bell                                    | <> Key                        |
| Character Mode                                  | '-Key                         |
| <b>Tab Set-Up Screen</b>                        |                               |
| <i>Leave this screen at the default values</i>  |                               |

**Table 11-4**  
**VT420 set-up values**

|                                                 |                              |
|-------------------------------------------------|------------------------------|
| <b>Global Set-Up</b>                            |                              |
| On Line                                         | Comm1=RS232                  |
| Sessions on Comm1                               | 70Hz                         |
| CRT Saver                                       | Printer Shared               |
| <b>Display Set-Up</b>                           |                              |
| 80 Columns                                      | No Status Display            |
| Interpret Controls                              | Cursor Steady                |
| Auto Wrap                                       | 3x24 pages                   |
| Jump Scroll                                     | 24 Lines/Screen              |
| Dark Screen                                     | Vertical Coupling            |
| Cursor                                          | Page Coupling                |
| Block Style Cursor                              | Auto Resize Screen           |
| <b>General Set-up</b>                           |                              |
| VT400 Mode, 7-bit Controls                      | Normal Cursor Keys           |
| User Defined Keys Unlocked                      | No New Line                  |
| User Features Unlocked                          | UPSS DEC Supplemental        |
| 8-bit Characters                                | VT420 ID                     |
| Application Keypad                              | When Available Update        |
| <b>Communications Set-Up</b>                    |                              |
| Transmit=1200 <i>(for Sys. Admin. terminal)</i> | Disconnect, 2 s Delay        |
| =2400 <i>(for Auxiliary terminals)</i>          | Limited Transmit             |
| Receive=Transmit                                | No Auto Answerback           |
| Xoff=64                                         | Answerback=                  |
| 8bits, No Parity                                | Not Concealed                |
| 1 Stop Bit                                      | Modem High Speed = ignore    |
| No Local Echo                                   | Modem Low Speed = ignore     |
| Data Leads Only                                 |                              |
| <b>Printer Set-Up</b>                           |                              |
| Speed=9600                                      | 8bits, No Parity, 1 Stop bit |
| No printer to Host                              | Print Full Page              |
| Normal Print Mode                               | Print National Only          |
| XOFF                                            | No Terminator                |
| <b>Keyboard Set-up</b>                          |                              |
| Typewriter Keys                                 | Ignore Alt                   |
| Caps Lock                                       | F1 = Hold                    |
| Auto Repeat                                     | F2 = Print                   |
| Keyclick High                                   | F3 = Set-Up                  |
| Margin Bell                                     | F4 = Session                 |
| Warning Bell High                               | F5 = Break                   |
| Character Mode                                  | , < and .> Keys              |
| <X] Delete                                      | <> Key                       |
| Local Compose                                   | '-Key                        |
| <b>Tab Set-Up</b>                               |                              |
| <i>Leave this screen at the default values</i>  |                              |

## HP700/22 terminals

Table 11-5 on page 11-9 contains the set-up values for the HP700/22 terminal. The set-up procedure is as follows:

- 1 Turn on the terminal.
- 2 Press **Setup** to enter set-up mode.  
*The current set-up values are displayed on a series of screens.*
- 3 Using the following procedures, change the values on each screen to match the values in Table 11-5.

To move through the set-up screens:

- a. Press **Next Screen** and **Prev Screen**

To change the value in a field:

- a. Use the arrow keys to move to that field.
  - b. Press **Enter** to move through the available values for that field.
- 4 When you've finished, press **Setup** again.

**Table 11-5**  
**HP700/22 set-up values**

|                                                |                                 |                          |        |
|------------------------------------------------|---------------------------------|--------------------------|--------|
| <b>General Set-up</b>                          |                                 |                          |        |
| Terminal Mode                                  | EM200, 7bit Ctrl                | EM100 ID                 | EM220  |
| On Line                                        | YES                             | Interpret Control Mode   | YES    |
| Columns                                        | 80                              | User Features Locked     | NO     |
| Smooth Scroll                                  | YES                             | User Defined Keys Locked | NO     |
| Block Cursor                                   | YES                             | Numeric Mode Keypad      | NO     |
| Cursor OFF                                     | NO                              | Normal Mode Cursor Keys  | YES    |
| Light Background                               | NO                              | National Character Set   | NO     |
| Inhibit Auto Wrap                              | NO                              | Frame Rate               | 72     |
| New Line                                       | NO                              | Display OFF After (min)  | 15     |
| Status Line                                    | Indicator                       | Multipage                | NO     |
| <b>Communications Set-up</b>                   |                                 |                          |        |
| <b>Host</b>                                    |                                 |                          |        |
| Xmit Baudrate                                  | 1200 (for Sys. Admin. terminal) | XON/XOFF                 | @ 64   |
|                                                | 2400 (for Auxiliary terminals)  | Disconnect Delay         | 2 s    |
| Recv Baudrate                                  | =Xmit                           | Stop Bits                | 1      |
| Data Bits/Parity                               | 8/None                          | Local Echo               | NO     |
| Check Parity                                   | NO                              | Unlimited Xmit           | NO     |
| Port Selection                                 | EIA, Data Leads Only            |                          |        |
| <b>Printer</b>                                 |                                 |                          |        |
| Baudrate                                       | 9600                            | Print Mode               | Normal |
| Data Bits/Parity                               | 8/None                          | Print Scroll Region      | NO     |
| Stop Bits                                      | 1                               | Terminator               | None   |
| Character Set                                  | National Only                   | XON/XOFF                 | @ 64   |
| <b>Keyboard Set-up</b>                         |                                 |                          |        |
| Keyboard Language                              | North American                  | Data Processing Keys     | NO     |
| Keyclick                                       | YES                             | Shift Lock               | NO     |
| Margin Bell                                    | YES                             | Break                    | YES    |
| Warning Bell                                   | YES                             | Auto Repeat              | YES    |
| Answerback=                                    |                                 | Auto Answerback          | NO     |
| <i>Do not set any tabs or programmed keys.</i> |                                 |                          |        |

## HP700/32 terminals

Table 11-6 on page 11-11 contains the set-up values for the HP700/32 terminal. The set-up procedure is as follows:

- 1 Turn on the terminal.
- 2 Press **Setup** to enter set-up mode.  
*The current set-up values are displayed on a series of screens.*
- 3 Using the following procedures, change the values on each screen to match the values in Table 11-6.

To move through the set-up screens:

- a. Press **Next Screen** and **Prev Screen**

To change the value in a field:

- a. Press **↑** and **↓** to move to that field.
- b. Press **←** and **→** to move through the available values for that field.

- 4** When you've finished, press **Setup** again.

**Table 11-6**  
**HP700/32 set-up values**

|                         |                                        |                                                |             |
|-------------------------|----------------------------------------|------------------------------------------------|-------------|
| <b>Global set-up</b>    |                                        |                                                |             |
| Host Port               | 2                                      | Keyboard                                       | U.S.        |
| Background              | Dark                                   | Message Translations                           | English     |
| Screen Saver            | 10 Min                                 | Setup Translations                             | English     |
| Refresh Rate            | 72 Hz                                  | Clear Display                                  |             |
| Key Click               | Yes                                    | Clear Comm                                     |             |
| <b>User Set-up</b>      |                                        |                                                |             |
| Smooth Scroll           | Jump scroll                            | Display Width                                  | 80          |
| Cursor Type             | Blink Line                             | Display Width Allowed                          | 80 or 132   |
| Cursor                  | Off                                    | Char Cell Height                               | 16          |
| 2nd Message Line        | On                                     | Clr on Width Change                            | Yes         |
| Message Line            | On                                     | Aux Mode                                       | Off         |
| Status Line             | On                                     | Aux to Host                                    | Off         |
| On Line                 | Yes                                    | Print Terminator=FF                            | No          |
| Local Echo              | Off                                    | Logical Page Size                              | 24          |
| Auto Wrap               | Off                                    | Number of Pages                                | 1           |
| Auto Linefeed           | Off                                    |                                                |             |
| Display Ctrl Codes      | Off                                    |                                                |             |
| <b>Emulation Set-up</b> |                                        |                                                |             |
| Emulation               | VT320                                  | Cursor Keys                                    | Normal      |
| Terminal Id             | VT220                                  | Print Scroll Region                            | Off         |
| Control Codes           | 7-bit                                  | User Features Locked                           | No          |
| Characters Mode         | 8-bit                                  | User Keys Locked                               | No          |
| Preferred Char Set      | DEC Supplemental                       | Data Procession Keys                           | No          |
| Key Pad Mode            | Application                            |                                                |             |
| <b>Port 1 Set-up</b>    |                                        |                                                |             |
| Communications          | Full Duplex                            | Limited Transmit                               | Off         |
| Data Length             | 8-bits                                 | DSRI                                           | No          |
| Parity                  | None                                   | CTS                                            | Ignore      |
| Stop Bits               | 1                                      | CD                                             | Ignore      |
| Xmit Baud               | 1200 <i>(for Sys. Admin. terminal)</i> | Break Disconnect                               | 170ms       |
|                         | 2400 <i>(for Auxiliary terminals)</i>  | Disconnect Delay                               | Never       |
| Recv Baud               | =Xmit                                  | Aux printer Type                               | National    |
| Xmit pace               | Xon/Xoff                               |                                                |             |
| Recv Pace               | Xoff at 128                            |                                                |             |
| <b>Port 2 Set-up</b>    |                                        |                                                |             |
| Communications          | Full Duplex                            | Xmit pace                                      | Xon/Xoff    |
| Data Length             | 8-bits                                 | Recv Pace                                      | Xoff at 128 |
| Parity                  | None                                   | Limited Transmit                               | Off         |
| Stop Bits               | 1                                      | Break Duration                                 | 170ms       |
| Xmit Baud               | 9600                                   | Aux Printer Type                               | National    |
| Recv Baud               | =Xmit                                  |                                                |             |
| <b>Keyboard Set-up</b>  |                                        |                                                |             |
| Lock Key                | Caps Lock                              | Warning Bell                                   | Yes         |
| Kbd Lock Enable         | Yes                                    | Auto Answerback                                | Yes         |
| Save Tabs               | Yes                                    | Answerback =                                   |             |
| Auto Repeat             | Yes                                    | Conceal Answerback                             | No          |
| Margin Bell             | Yes                                    | <i>Do not set any tabs or programmed keys.</i> |             |





---

## Disk drive configuration

---

The following is a list of the disk drives supported by Northern Telecom and the page containing each drive's configuration instructions.

If the drive you're installing does not appear in the following list, consult the latest version of the release bulletin for this guide. Release bulletins are released periodically as new disk drives are added to the Meridian Mail card option product list.

If the drive you're installing is not supported by Northern Telecom, refer to the disk drive's manual for the location of the terminator plugs and the jumper configurations. For a disk drive to function correctly with the Meridian Mail card option, it must have no terminators, its SCSI address must be set to zero, its parity must be enabled, and its motor must be set to start up when the power is turned on.

### **Maxtor drives**

|                            |                          |
|----------------------------|--------------------------|
| Maxtor 7080S & 7080SR      | Figure 12-1 on page 12-2 |
| Maxtor 7080S-C             | Figure 12-2 on page 12-2 |
| Maxtor 7120S               | Figure 12-3 on page 12-3 |
| Maxtor LXT340SY (option A) | Figure 12-4 on page 12-3 |
| Maxtor LXT340SY (option B) | Figure 12-5 on page 12-4 |


### **Quantum drives**

|                      |                          |
|----------------------|--------------------------|
| Quantum ProDrive 80S | Figure 12-6 on page 12-4 |
|----------------------|--------------------------|


### **Seagate drives**

|                 |                           |
|-----------------|---------------------------|
| Seagate ST1096N | Figure 12-7 on page 12-5  |
| Seagate ST1201N | Figure 12-8 on page 12-5  |
| Seagate ST1480N | Figure 12-9 on page 12-6  |
| Seagate ST3390N | Figure 12-10 on page 12-7 |


**Figure 12-1**  
**Maxtor 7080S & 7080SR disk drive configuration**




**Figure 12-2**  
**Maxtor 7080S-C disk drive configuration**




**Figure 12-3**  
**Maxtor 7120S disk drive configuration**




**Figure 12-4**  
**Maxtor LXT340SY disk drive configuration (option A)**




**Figure 12-5**  
**Maxtor LXT340SY disk drive configuration (option B)**




**Figure 12-6**  
**Quantum ProDrive 80S disk drive configuration**




**Figure 12-7**  
**Seagate ST1096N disk drive configuration**




**Figure 12-8**  
**Seagate ST1201N disk drive configuration**



**Figure 12-9**  
**Seagate ST1480N disk drive configuration**



**Figure 12-10**  
**Seagate ST3390N disk drive configuration**







---

## List of terms

---

**AML**

The Application Module Link is the communications link established between Meridian Mail and the Meridian 1 switch.

**DCE**

Data communications equipment

**DN**

DN or directory number is the number you dial to reach a user's extension or a Meridian Mail service. Directory numbers are also used to define virtual ACD agent positions responsible for handling Meridian Mail calls.

**DTE**

Data terminal equipment

**Hardware location**

A hardware location is the physical circuitry on the DVP and C25 cards used to process fax and voice data. Each card has two hardware locations. These hardware locations are assigned to ports. A basic or full-service voice port requires one hardware location. A multimedia port requires two hardware locations.

**HVS**

Hospitality Voice Services

**MDF**

Main Distribution Frame

**PBX**

Private branch exchange. The portion of the Meridian 1 system that manages the electronic switching of calls.

**PMS**

Property management system. A standard computer system used by many hotels which can be connected to Meridian Mail hospitality systems.

**Port**

There are two types of port in the Meridian Mail Card Option system. The first type of port is used to move data between Meridian Mail and the Meridian 1 PBX, using the hardware locations on the DVP and C25 cards. The second type of port is used to move data between Meridian Mail and peripheral devices such as modems and printers, using the hardware on the RSM card.

**RSM**

RS-232 service module

**SCSI**

Small Computer System Interface. An international standard for data communication.

**SEERs**

System error and events reports

---

# Index

---

68k Card

Installation 1-7-1-8

## A

ACD agent defaults 10-2

Adding blocks of users 3-17, 4-10-4-11

AML 13-1

Application Module Link 13-1

Assumptions ix

Automated Attendant

Defining 3-8-3-13

DN 10-2

## B

Backing up Meridian Mail 4-7-4-9

Scheduling backups 4-8-4-9

Basic multimedia port 2-5-2-6

Basic voice port 2-5-2-6

## C

C25 Card

Adding 7-2-7-3

Installation 1-9-1-10

Configuring telephone sets 3-6-3-7

Connector Board

Installation 1-13-1-14

Removal 5-3-5-4

Converting software 6-1-6-3

## D

Data port locations 3-4, 7-7

DCE 13-1

Defective tapes 5-9-5-10

Deleting blocks of users 4-11-4-12

Dialing restrictions 3-7-3-8

Disk drive

Configuration 12-1-12-7

Maxtor 7080S 12-2

Maxtor 7080S-C 12-2

Maxtor 7080SR 12-2

Maxtor 7120S 12-3

Maxtor LXT340SY 12-3-12-4

Quantum ProDrive 80S 12-4

Seagate ST1096N 12-5

Seagate ST1201N 12-5

Seagate ST1480N 12-6

Seagate ST3390N 12-7

Installation 1-11

Part numbers 1-1

Storage expansion 7-3-7-5

Disk shield 1-11

Part number 1-1

Disk/Power Supply Card

Installation 1-11-1-12

DN 13-1

DSP parameters 10-1

DTE 13-1

DVP Card

Adding 7-2-7-3

Installation 1-9-1-10

## E

Enabling and disabling data ports 4-3-4-5

Express messaging DN

Basic systems 10-2

Defining 3-14, 3-16

Hospitality systems 10-3

## F

Full-service multimedia port 2-5-2-6

Full-service voice port 2-5-2-6

## G

Guest messaging DN 10-3

Defining 3-15

## H

Hardware locations 13-1

Configuring 2-5-2-7

Hardware modification 7-2-7-3

Hospitality system service DN's

Defaults 10-3

Defining 3-14-3-17

Express messaging 10-3

Guest messaging 10-3

Hotel menu 10-3

Post checkout 10-3

Published numbers 10-3

Staff messaging 10-3

Hospitality Voice Services

Administration 8-4

Installation 8-1-8-6

Hotel menu DN 3-8, 10-3

Defining 3-15-3-16

HP700/22 terminal configuration 11-8-11-9

HP700/32 terminal configuration 11-9-11-11

HVS 13-1

## K

Keycode label 2-3, 7-1

Keycodes 2-1-2-4, 3-1, 6-1-6-2, 7-1

## L

Label, keycode 2-3, 7-1

Languages

Adding 7-5-7-6

List of available 2-2

LED

Blinking 5-4-5-8

Location 1-8

## M

Maintenance 5-15-5-17

MDF 13-1

Meridian 1 PBX

Logging on 4-1-4-2

Recommended reading xii

Meridian Mail

Backing up 4-7-4-9

Restoring 4-9-4-10

Scheduling backups 4-8-4-9

Starting 4-6-4-7

Stopping 4-5

Turning off 4-5-4-6

Meridian Mail defaults 10-1-10-3

Changing 4-12-4-23

Meridian Mail power switch location 1-8

Modem

Configuration 9-3-9-5

Part number 9-1

Problems 5-12

Mu-law 10-1

Multimedia port 2-5-2-6

Multiport cable 8-2

**N**

- Networking
  - Administration 9-5
  - Installation 9-1-9-5
- NT220 terminal configuration 11-1-11-3
- NTAK13AA (Disk/Power Supply Card)
  - Installation 1-11-1-12
- NTAK14BA (68k Card)
  - Installation 1-7-1-8
- NTAK15AA (DVP Card, older model) 1-9
- NTAK15AB (DVP Card)
  - Adding 7-2-7-3
  - Installation 1-9-1-10
- NTAK16AA (C25 Card, older model) 1-9
- NTAK16AB (C25 Card)
  - Adding 7-2-7-3
  - Installation 1-9-1-10
- NTAK17AA/AB (Connector Board)
  - Installation 1-13-1-14
  - Removal 5-3-5-4
- NTAK18AA/BA (RSM Breakout Assembly)
  - Installation 1-5-1-6
- NTAK19AA/BA (Multiport cable) 8-2

**O**

- Optional features
  - Adding 7-6-7-8
  - Hospitality Voice Services
    - Administration 8-4
    - Installation 8-1-8-6
  - List of available 7-6
  - Networking
    - Administration 9-5
    - Installation 9-1-9-5
  - Recommended reading xii

**P**

- Passwords 10-1

- PBX 13-1
- Port 13-2
- Post check-out DN
  - Defining 3-16
- Post checkout DN 10-3
- Power switch location 1-8
- Precautions 1-3-1-4, 5-2-5-3
- Printer
  - Installation 1-16-1-21
- Prompt maintenance DN 10-2
- Published numbers DN 10-3
  - Defining 3-16

**R**

- Replacing components 5-3-5-4
- Restoring Meridian Mail 4-9-4-10
- RSM 13-2
- RSM Breakout Assembly
  - Hospitality systems 8-2
  - Installation 1-5-1-6
  - Networked systems 9-1
  - Switch 8-2

**S**

- Scheduling backups 4-8-4-9
- SCSI 13-2
- Security concerns 3-2, 3-17
- SEER printer
  - Installation 1-16-1-21
- SEERs 1-17, 5-14-5-15, 13-2
- Serial numbers 2-2-2-3
- Setting the time and date 4-2-4-5
- 68k Card
  - Installation 1-7-1-8
- Software
  - Conversions 6-1-6-3
  - Installation 3-1-3-17
  - Upgrades 6-1-6-3
    - Problems 5-8

- Spares planning 5-14-5-15
- Staff messaging DN 10-3
  - Defining 3-16-3-17
- Starting Meridian Mail 4-6-4-7
- Stopping Meridian Mail 4-5
- Storage expansion 7-3-7-5
  - Problems 5-8
- System Administrator 3-8
- System expansion
  - Problems 5-8
- System installation and modification utility
  - 2-4-2-7

## T

- Tape
  - Backup 4-7-4-9
  - Defective 5-9-5-10
  - format 1-3
  - insertion 1-15-1-16
  - removal 1-16
- Tape drive
  - Accessories 1-3
  - Cleaning 5-16-5-17
  - Installation 1-14-1-15, 5-15-5-16
  - Mounting 1-15
  - Part numbers 1-3
  - Problems 5-8-5-10
  - Removal 1-16
- Telephone set configuration 3-6-3-7
- Terminal configuration 11-1-11-11
  - HP700/22 11-8-11-9
  - HP700/32 11-9-11-11
  - NT220 11-1-11-3
  - VT220 11-3, 11-5
  - VT320 11-3, 11-6
  - VT420 11-3, 11-7
- Terminals
  - Hospitality systems 8-1
  - Problems 5-10-5-12

- Time and date setting 4-2-4-5
- Tools menu 4-10-4-12
- Troubleshooting 5-1-5-15
- Turning Meridian Mail off 4-5-4-6

## U

- Upgrading software 6-1-6-3

## V

- Ven-Tel modem configuration 9-3-9-5
- Voice mail
  - Problems 5-12-5-14
- Voice Messaging DN
  - Changing 4-12-4-15
  - Default 10-2
  - Defining 3-13-3-14
- Voice port 2-5-2-6
- Voice Prompt Maintenance DN
  - Defining 3-14
- Voice service DN's
  - Automated Attendant 10-2
  - Changing 4-15
  - Defaults 10-2
  - Express messaging
    - Basic systems 10-2
    - Hospitality systems 10-3
  - Guest messaging 10-3
  - Hotel menu 10-3
  - Networked systems 10-3
  - Post checkout 10-3
  - Prompt maintenance 10-2
  - Published numbers 10-3
  - Staff messaging 10-3
  - Voice Messaging 10-2
- VT220 terminal configuration 11-3, 11-5
- VT320 terminal configuration 11-3, 11-6
- VT420 terminal configuration 11-3, 11-7



Meridian 1 Option 11  
**Meridian Mail Card Option**  
Installation and Maintenance

Address comments to:  
Customer Documentation  
Northern Telecom Canada Limited  
522 University Avenue, 14th floor  
Toronto, Ontario, Canada  
M5G 1W7

Copyright © 1994 Northern Telecom  
All rights reserved

The information contained in this guide is subject to change without notice. Northern Telecom reserves the right to make changes in design or components as progress in engineering or manufacturing may warrant. BIX, Generic X11, Meridian 1, and Meridian Mail are trademarks of Northern Telecom. Other products mentioned in this guide may be trademarks or registered trademarks of their respective companies and are hereby acknowledged.

NTP number: 555-7071-210

Publication number: P0746551

Software release: 9.0

Document version: Standard 3.0

Date: March 1994

Printed in the United States of America

